


165 R



1. 1980

Reservdelar


Spare parts

Ersatzteile

Pièces de rechange


Varaosat

A




502 01 26-01
502 00 25-01

B * compl 501 41 78-01



501 21 66-02 (CJ7Y)
501 21 66-07 (WS7F)
206 33 29-11
502 01 02-01
202 43 33-55
288 81 70-01
501 28 93-01
501 53 93-02(A+B)
501 59 39-04(C)
501 53 93-05(D+E)
*
* 501 51 12-01
*
* 501 15 28-01
* 501 05 64-01


C



502 01 36-01
501 28 92-01
502 00 10-01
258 11 31-52
502 01 20-01
502 01 76-01
502 00 68-01
501 25 10-01
204 13 06-09


F

* compl 501 55 61-02



501 15 28-01 *
293 11 95-04 *
293 11 95-04 *
290 12 30-01 *


E



501 25 21-01
502 00 27-01
502 01 46-01
502 01 66-01
200 63 82-42
206 33 28-11


G

* compl 502 00 16-01



502 02 33-01 *
502 00 23-01 *
297 13 42-01 *
502 02 87-01
502 01 39-01 *
502 00 18-01 *
502 01 80-01 *
501 51 83-01 *


D * compl 502 01 20-01




50 12 234-01
 Packningssats
 Set of gaskets
 Dichtungssatz
 Jeu de joints
 Tiivistesrj

50 15 467-01
 Reservdelssats
 Spare part kit
 Ersatzteilsatz
 Jeu de piéces de rechange
 Varuusasrj


K



H




J




L

* compl 502 00 14-01




M

* compl 502 00 36-01



N




P


**Tillbehör
Accessories**

**Zubehöre
Accessoires**

Tarvikkeet




502 01 94-01 9" Sandvik XRT
502 01 95-02 9" Maxi 225




501 58 02-01
501 07 21-01

502 01 71-01


501 31 77-01



502 02 75-01




502 04 70-01



502 50 76-01

R

502 02 00-01 = Compl.




502 02 01-01

502 02 06-01

502 02 38-01
502 02 30-02
289 52 20-01
502 02 29-02
502 02 27-01

S

★ 502 04 70-01 = Compl.



502 04 71-01 (M 10)
502 04 71-02 (M 12)

502 04 72-01

502 04 73-01
502 04 77-01 (50 ft)
502 04 83-01 (250 ft)

502 04 74-01

502 04 75-01

502 04 76-01