


Parts List: Stand Assembly

Index No.	Part No.	Description	Size	Qty
1.....	PJ1285-101.....	Stand		1
2.....	TS-0680041.....	Flat Washer	3/8"	4
3.....	TS-0720091.....	Lock Washer	3/8"	4
4.....	TS-0060051.....	Hex Cap Screw	3/8"-16x1"	4
5.....	6292491.....	Cover, Dust Chute		1
6.....	TS-081C022.....	Machine Screw, Pan Head, Phillips	#10-24x3/8"	5
7.....	6292493.....	Motor Assembly, Motor With Pulley3HP, 3Ph	1
	6295366.....	Motor Assembly, Motor With Pulley3HP, 1Ph	1
8.....	6292494.....	Plate, Switch		1
9.....	6295112.....	Contactor1Ph	1
	6292495.....	Contactor3Ph, 230V	1
	PJ1285-109.....	Contactor3Ph, 460V	1
10.....	PJ1285-110.....	Clamp3Ph	3
	PJ1285-110A.....	Clamp1Ph	3
11.....	6292497.....	Box, Junction		1
12.....	6292498.....	Strip, Terminal		1
13.....	TS-081C062.....	Machine Screw, Pan Head, Phillips	#10-24x1"	2
14.....	TS-0720051.....	Lock Washer	#10	2
15.....	PJ1696-211.....	Switch		1
16.....	PJ1285-116.....	Hood, Dust		1
17.....	TS-0720071.....	Lock Washer	1/4"	9
18.....	TS-0050011.....	Hex Cap Screw	1/4"-20x1/2"	7
19.....	6292507.....	Cover, Pulley		1
20.....	6292508.....	Bolt		3
22.....	TS-0561031.....	Hex Nut	3/8"-16	6
23.....	TS-059303.....	Cap Nut	3/8"-16	3
24.....	6292510.....	Door, Access		1
25.....	6292511.....	Handle Assembly		1
26.....	PJ1285-126.....	Washer3/8"x3/4 OD	1
27.....	PJ1696-210.....	Switch Arm		1
28.....	TS-1533052.....	Machine Screw, Pan Head, Phillips	M5x16	2
29.....	PJ1285-129.....	Switch Cord		1
30.....	PJ1285-130.....	Motor Cord1Ph	1
	PJ1285-130A.....	Motor Cord3Ph	1
31.....	PJ1285-131.....	Power Cord1Ph	1
	PJ1285-131A.....	Power Cord3Ph	1
32.....	3312341.....	Powermatic Logo		1


Stand Assembly



Parts List: Table Assembly

Index No.	Part No.	Description	Size	Qty
1.....	6292525.....	Base		1
2.....	6292526.....	Bar, Table Raising Link		2
3.....	6292527.....	Bracket		2
4.....	TS-0680041	Lock Washer	3/8"	8
5.....	TS-0209051	Socket Head Cap Screw	3/8"-16x1"	4
6.....	6292530.....	Bushing.....		8
7.....	6292531.....	Support.....		8
8.....	6292532.....	Bushing.....		8
9.....	6292533.....	Axis, Pivot		4
10.....	6292534.....	Screw		2
11.....	TS-0680061	Flat Washer.....	1/2"	2
12.....	6292536.....	Handwheel.....		2
13.....	6292537.....	Handle		2
14.....	TS-0209061	Socket Head Cap Screw	3/8"-16x1-1/4"	4
15.....	TS-1490041	Hex Cap Screw	M8x25.....	2
16.....	TS-1540061	Hex Nut.....	M8.....	4
17.....	6292540.....	Knob		2
18.....	6292541.....	Axis, Pivot		8
19.....	TS-0208071	Socket Head Cap Screw	5/16"-18x1-1/4"	8
20.....	6292543.....	Bar, Table Raising Link		2
21.....	6292544.....	Axis, Pivot		4
22.....	6292545.....	Screw		8
23.....	TS-0561031	Hex Nut.....	3/8"-16.....	24
24.....	6292547.....	Tube		2
25.....	6292548.....	Spring		4
26.....	PJ1696-509.....	Spring Holding Bolt		4
27.....	6292550.....	Straight Cutterhead Assembly		1
.....	PJ1285-600.....	Helical Cutterhead Assembly.....		1
28.....	TS-1491041	Hex Cap Screw	M10x30.....	2
29.....	6292551.....	Infeed Table		1
30.....	6292552.....	Lip, Table		1
31.....	TS-1505061	Socket Head Cap Screw	M10x40.....	8
32.....	6292554.....	Deflector, Dust.....		1
33.....	TS-081C062	Machine Screw, Pan Head, Phillips	#10-24x1".....	5
34.....	TS-0680011	Flat Washer.....	3/16".....	5
35.....	TS-0560071	Hex Nut.....	#10-24.....	5
36.....	6292558A.....	Outfeed Table		1
37.....	6292559.....	Lip, Table		1
38.....	6292560.....	Guard Assembly		1
39.....	TS-2361101	Lock Washer	M10.....	2
40.....	PJ1285-240.....	Pointer		1
41.....	PJ1285-241.....	Scale		1
42.....	TS-0680011	Flat Washer.....	3/16".....	1
43.....	TS-081C022	Machine Screw, Pan Head, Phillips	#10-24x3/8".....	1
44.....	TS-0680041	Flat Washer.....	3/8".....	24
45.....	TS-0271051	Socket Set Screw	3/8"-16x1/2".....	4
46.....	TS-0271031	Socket Set Screw	3/8"-16x3/8".....	4
47.....	TS-0561011	Hex Nut.....	1/4"-20.....	6
48.....	6285917.....	Push Block		2
49.....	PJ1285-249.....	Set Screw	M8x35.....	2
50.....	PJ1285-250.....	Dust Deflector		1
51.....	PJ1285-251.....	Steel Plate		1
52.....	TS-1502051	Socket Head Cap Screw	M5x20.....	2


Table Assembly



Parts List: Motor Pulley Assembly

Index No.	Part No.	Description	Size	Qty
1.....	6292512.....	Motor.....	3HP 3Ph	1
.....	6292512-MF	Motor Fan (not shown)	1
.....	6292512-MFC	Motor Fan Cover (not shown)	1
.....	6292563.....	Motor.....	.3HP 1Ph	1
.....	6292563-MF	Motor Fan (not shown)	1
.....	6292563-MFC	Motor Fan Cover (not shown)	1
.....	6292563-CS	Centrifugal Switch (not shown)	1
.....	6292563-SC	Starting Capacitor (not shown)	400MFD, 250VAC.....	1
.....	6292563-RC	Running Capacitor (not shown)	50uf, 350VAC.....	1
2.....	6292513.....	Pulley.....	.3Ph.....	1
.....	6294246.....	Pulley.....	.1Ph.....	1
3.....	TS-1525011	Socket Screw Screw	M10x10.....	1
4.....	6292515.....	Bracket, Motor.....	1
5.....	TS-0680041	Flat Washer.....	.3/8".....	3
6.....	TS-0720091	Lock Washer3/8".....	6
7.....	TS-0060081	Hex Cap Screw3/8"-16x1-3/4".....	3
8.....	TS-0561031	Hex Nut.....	.3/8"-16.....	3
9.....	6292520	Plate	1
10.....	6292521	Rod	1
11.....	TS-2360121	Flat Washer.....	M12	2
12.....	TS-1540081	Hex Nut.....	M12	8
13.....	TS-1525021	Socket Set Screw	M10x12.....	1
14.....	6295367	Belt, 1PH.....	A-53.....	2
.....	6295357	Belt, 3PH.....	A-55.....	2
15.....	PJ1285-315.....	Key8mmx 7mm x 55mm	1


Motor Pulley Assembly



Parts List: Cutterhead Guard Assembly

Index No.	Part No.	Description	Size	Qty
1.....	6292581.....	Ledge, Rabbet.....		1
2.....	6292582.....	Guard		1
3.....	6292583.....	Shaft.....		1
4.....	6292584.....	Spring		1
5.....	6292585.....	Collar, Shaft		1
6.....	TS-0271071	Socket Set Screw3/8"-16x3/4"	1
7.....	TS-0267071	Socket Set Screw	1/4"-20x3/4"	2
8.....	TS-0561011	Hex Nut.....	1/4"-20.....	2
9.....	6292589.....	Knob		1
10.....	TS-0720091	Lock Washer3/8"	2
11.....	TS-0209031	Socket Head Cap Screw3/8"-16x3/4"	2
12.....	TS-0680041	Flat Washer.....	.3/8"	2
13.....	60B-272	Warning Label		1


Cutterhead Guard Assembly



Parts List: Straight Cutterhead Assembly

Index No.	Part No.	Description	Size	Qty
.....	6292550	Cutterhead Assembly (Items 1 thru 19).....		
1.....	6292561	Cutterhead		1
2.....	PJ1696-002	Left Bearing Housing		1
3.....	BB-6204ZZ	Bearing	6204ZZ	2
4.....	PJ1696-005	Right Bearing Housing		1
5.....	BB-6206ZZ	Bearing	6206ZZ	2
6.....	6292566	Bearing Washer.....		1
7.....	6292568	Hex Cap Screw (LH Threads).....	M8x20	1
8.....	TS-1503051	Socket Head Cap Screw	M6x20	6
9.....	6292572	Pulley.....		1
10.....	6292573	Key8mmx8mmx60mm	1
11.....	6292574	Pulley Washer		1
12.....	TS-2361101	Lock Washer	M10	1
13.....	6292576	Hex Cap Screw (LH Threads).....	M10x25	1
14.....	6292577	Spring		6
15.....	6292535	Knife (set of 3).....		1
16.....	6292579	Gib, Knife(set of 3).....		1
17.....	6292580	Gib Screw		18
18.....	PJ1696-004	Left Bearing Cap Plate		1
19.....	PJ1696-006	Right Bearing Cap Plate		1
.....	PJ1285-KSGA	Knife Setting Gauge Assembly (Items 20 thru 23)		1
20.....	PJ1285-520	Handle		1
21.....	PJ1285-521	Setting Gauge		2
22.....	TS-1482051	Hex Cap Screw	M6x25	2
23.....	TS-2361061	Lock Washer	M6	2


Straight Cutterhead Assembly



Parts List: Helical Cutterhead Assembly

Index No.	Part No.	Description	Size	Qty
	PJ1285-600	Cutterhead Assembly (Items 1 thru 22)		
1	PJ1285-601	Cutterhead		1
2	PJ1696-002	Left Bearing Housing		1
3	BB-6204ZZ	Ball Bearing	.6204ZZ	2
4	6292566	Bearing Washer		1
6	TS-1490031	Hex Cap Screw	M8x20	1
7	PJ1696-004	Left Bearing Cap Plate		1
8	TS-1503051	Socket Head Cap Screw	M6x1.0Px20L	6
9	PJ1696-005	Right Bearing Housing		1
10	BB-6206ZZ	Bearing	.6206ZZ	2
11	PJ1696-006	Right Bearing Cap Plate		1
12	6292573	Key	.8mm x .8mm x 60mm	1
13	6292572	Cutterhead Sheave		1
14	6292574	Pulley Washer		1
15	TS-2361101	Lock Washer	M10	1
16	TS-1491021	Hex Cap Screw	M10x20	1
17	PJ1696-010	Gib		44
18	PJ1696-011	Carbide Insert Knife-Rabbet (Sold in pkg of 2)		2
19	6400013	Carbide Insert Knife (Sold in pkg of 10)		42
20	PJ1696-012	Gib Nut		44
21	PJ1696-013	Gib Screw		44
22	PJ1696-015	Gib Pin	Ø 2x8	88


Helical Cutterhead Assembly




Parts List: Fence Assembly

Index No.	Part No.	Description	Size	Qty
1.....	6292592.....	Support, Fence.....		1
2.....	6292593.....	Bracket		1
3.....	6292594.....	Column, Gear.....		1
4.....	6292595.....	Guard		1
5.....	TS-1503031	Socket Head Cap Screw	M6x12.....	2
6.....	TS-1550071	Flat Washer.....	M10.....	4
7.....	TS-2361101	Lock Washer	M10.....	4
8.....	TS-1491041	Hex Head Bolt	M10x30.....	2
9.....	TS-1505041	Socket Head Cap Screw	M10x30	2
10.....	6292601	Shaft,Gear		1
11.....	6292602.....	Handwheel		1
12.....	6292603.....	Lock Handle		1
13.....	6295358.....	Collar		1
14.....	6292604.....	Bolt		1
15.....	TS-0720111	Lock Washer	1/2".....	2
16.....	6295886.....	Socket Head Cap Screw	1/2"-12NCx1-1/4".....	2
17.....	6292605.....	Bracket, Fence		1
18.....	6292606.....	Support		1
19.....	6292607	Pin		6
20.....	TS-1523061	Socket Set Screw	M6x20.....	2
21.....	TS-1540061	Hex Nut.....	M8.....	4
22.....	TS-1490031	Hex Cap Screw	M8x20.....	2
23.....	6292611.....	Bracket, Left		1
24.....	6292612.....	Bracket, Right		1
25.....	6292613.....	Shaft.....		1
26.....	TS-2360121	Flat Washer.....	M12.....	2
27.....	6292615.....	Lock Handle		1
28.....	TS-2331121	Cap Nut	M12.....	1
29.....	6292823.....	Spring Pin	Ø5x20.....	1
30.....	6295359.....	Clamp,Rear		2
31.....	6295360.....	Fence		1
32.....	TS-1540081	Hex Nut.....	M12.....	1
33.....	6295362.....	Rod		1
34.....	6292540.....	Knob		1
35.....	6295364.....	Block		1
36.....	6295365.....	Bushing		1
37.....	TS-2361081	Lock Washer	M8.....	1
38.....	TS-1490061	Hex Cap Screw	M8x35.....	1
39.....	PJ1285-739.....	Cover		1
40.....	PJ1696-105.....	Block		1
41.....	TS-1501051	Socket Head Cap Screw	M4x16.....	1
42.....	TS-1523041	Socket Set Screw	M6x12.....	1
43.....	TS-1540071	Hex Nut.....	M10.....	1
44.....	TS-1550061	Flat Washer.....	M8.....	1
45.....	TS-1490061	Hex Cap Screw	M8x35.....	2
46.....	TS-1505021	Socket Head Cap Screw	M10x20.....	4

Fence Assembly



Electrical Connections – 1 Phase



Electrical Connections – 3 Phase

