





Parts List for 36-714B Type 1

Item Number	Part Number	Description	Qty Required
1	1313270	PUSH NUT	2
2	1313271	PIN	1
3	A06320	GUARD	1
3	A06457	GUARD ASSY	1
4	1313273	PIN	1
5	1313274	BRACKET	1
6	1313275	LOCK RING	1
7	1313276	SPRING	1
8	A13496	SCREW	1
9	1344975	SPLITTER	1
10	A06314	BRACKET	1
11	904010101620S	WASHER	7
12	902010101300S	HEX NUT	1
13	901010600626S	CAP SCREW	2
14	491957-00	LOCK WASHER	2
15	904010312934S	WASHER	2
16	1310062	WASHER	3
17	901030100755S	CAP SCREW	1
18	901030100230S	SCREW	1
19	A06331	BRACKET	1
20	1344977	PLATE	1
21	901010600649S	CAP SCREW	5
22	912856	WING	1
22	A01413	WING	1
23	901010600664S	CAP SCREW	6
24	904020101716	LOCK WASHER	6
25	904020101606	WASHER	6

Parts List for 36-714B Type 1

Item Number	Part Number	Description	Qty Required
26	1346470	SET SCREW	2
27	A06307	TABLE	1
28	901044615297	SCREW	4
29	A06327	TABLE INSERT	1
30	1310006	SCREW	1
31	491889-00	SCREW HEX HEAD	2
33	488822-00	FLAT WASHER	10
40	1310311	ROLL PIN	1
41	1313279	ANTI-KICKBACK FINGER	2
50	A06460	SCREW	2
51	A06336	SWITCH ASSY	1
52	A06459	SWITCH	1
53	A06322	SWITCH BOX	1
54	898187	SCREW	2
55	488983-00	LOCK WASHER	4
56	A06317	SWITCH SUPPORT	1
57	A08159	SCREW	4
58	A06466	SWITCH	1
59	642365	SWITCH ASSEMBLY	1
60	TSS3014460	POWER CORD	1
61	A06335	CORD ASSY.	1
62	489587-00	STRAIN RELIEF	1
70	36-946	MITER GAUGE ASSY	1
200	A06325	ARBOR NUT	1
201	1344991	FLANGE	1
202	A06328	ARBOR SHAFT	1
203	1086894S	BEARING	1

Parts List for 36-714B Type 1

Item Number	Part Number	Description	Qty Required
204	928060207382S	LOAD SPRING	2
205	1344994	SHAFT	1
206	1344993	SPACER	1
207	A06311	BRACKET	1
208	1344933	SCREW	3
209	A08147	KEY	1
210	1344996	BEARING CLOSURE NUT	1
211	1344997	SPACER	1
212	A06330	ARBOR PULLEY	1
213	902010201226S	NUT	2
214	1345000	BRACKET	1
215	904010101604S	STEEL WASHER	2
216	1343390	SPRING WASHER	8
218	902012831393	LOCK NUT	4
219	A06310	REAR TRUNNION	1
220	A06332	1.75HP/1PH MOTOR	1
221	A08148	KEY	1
222	A06329	MOTOR PULLEY	1
223	1246008	SET SCREW	1
224	A06454	BELT	1
225	1246017	CAP SCREW	4
226	A06456	PIN	1
227	A06308	MOTOR BRACKET	1
228	491964-00	NUT	4
229	488813-00	LOCK WASHER	4
231	1347293	LOCK NUT	3
232	A08151	STUD	1

Parts List for 36-714B Type 1

Item Number	Part Number	Description	Qty Required
233	A06326	SPRING	1
234	A08152	STUD	1
235	A08153	WASHER	1
242	1345086	SHIM	7
243	1344989	TIE BAR	2
244	1313289	WASHER	1
246	1344988	ELEVATING SHAFT ASSY	1
247	000000-00	No Longer Available	2
248	1243339	SCREW	1
249	488808-00	LOCK WASHER	1
250	A06309	FRONT TRUNNION	1
251	1344986	SLEEVE	1
252	1344981	SPACER	1
253	A06315	BRACKET	1
254	A07810	CURSOR	1
255	A06462	SCREW	1
256	A06375	HANDWHEEL ASSY	2
257	1313239	WASHER	2
258	651140-00	KNOB	2
259	000000-00	No Longer Available	2
261	1344984	TILT SHAFT ASSY	1
262	1344983	ECCENTRIC	1
266	491950-00	SET SCREW	4
267	A06373	BRACKET	1
268	1345084	JAM NUT	1
269	489192-00	FIBER WASHER	2
270	1344985	COLLAR	2

Parts List for 36-714B Type 1

Item Number	Part Number	Description	Qty Required
271	902015031514	FLANGED HEX NUT	2
272	1344604	BRACKET	1
273	901020100506	MACHINE SCREW	2
277	884298	HEX WRENCH (4MM)	1
278	1313232	WRENCH	1
279	955010501482	WRENCH	1
302	489047-00	CAP SCREW	4
303	A06464	BEVEL SCALE	1
304	A06463	SCREW	4
305	A23692	NAME PLATE	1
306	A14323	RIVET	4
307	A06319	CABINET	1
308	1347527	SCREW	1
309	1343545	WASHER	5
310	488910-00	CABLE CLAMP	1
311	489093-00	HEX NUT	1
312	1348301	NUT	4
313	652332-00	SUB BASE	1
316	A08155	SCREW	14
317	A06318	SIDE PANEL	1
319	A08150	SCREW	4
320	422350600001S	WRENCH HOOK	1
321	A06374	BRACKET	2
322	A06312	MOTOR COVER	1
323	A06372	LATCH	2
324	A06323	RUBBER GASKET	1
325	A06313	RAMP	1

Parts List for 36-714B Type 1

Item Number	Part Number	Description	Qty Required
328	A07808	SCREW	4
329	406120260001S	DUST CHUTE	1
330	A08156	SCREW	4
331	1345893	NUT	4
332	A07807	SLIDE PLATE	1
333	1313218	PIN	3
340	A07808	SCREW	4
355	1234908	INSULATOR	1