









Parts List for 37-361 Type 1

Item Number	Part Number	Description	Qty Required
1	1342002	SCREW	7
2	1347725	DUST HOOD	1
3	1347712	DUST CHUTE COVER	1
4	1341046	SCREW	3
5	1347746	RUBBER WASHER	4
6	1243360	LOCKWASHER	4
7	1246115	CAP SCREW	4
8	1330158	SCREW	3
9	1243502	WASHER	6
10	1347716	MOTOR 3PH 3HP	1
10	1347715	MOTOR 1PH 3HP	1
11	1243494	SCREW	1
12	1347704	KEY	1
13	1347718	MTR PULLEY 24MM 3PH	1
13	1349782	MTR PULLEY 28MM 1PH	1
14	1243496	NUT-STEEL	4
15	1341945	FLAT WASHER	2
16	1347714	PLATE	1
17	1347713	ROD	1
18	1243496	NUT-STEEL	3
19	1347711	MOTOR BRACKET	1
20	1243496	NUT-STEEL	4
21	1243501	SCREW	1
22	1347720	TERMINAL STRIP	1
23	1243501	SCREW	4
24	1320102	LOCK WASHER	2
25	1347719	JUNCTION BOX	1

Parts List for 37-361 Type 1

Item Number	Part Number	Description	Qty Required
26	1341165	HEX HEAD SCREW	3
27	1243476	NUT	3
28	000000-00	No Longer Available	3
29	1347709	MOUNTING PLATE	1
30	1347708	CABINET	1
30	A26359	NAMEPLATE	1
31	1347723	PULLEY COVER	1
31	1347724	LATCH	2
31	000000-00	No Longer Available	4
32	1347710	ACCESS DOOR	1
33	1347733	HANDLE ASSY	1
34	1347722	CONTACTOR 3PH	1
34	1347721	CONTACTOR 1PH	1
35	1347829	COIL 440V	1
36	1341046	SCREW	3
101	1347727	GUARD	1
102	1349523	WARNING LABEL	1
103	A26362	WARNING LABEL	1
104	1347702	SCREW	1
105	1347731	SPECIAL WASHER	1
106	1243339	SCREW	2
107	1347730	ADAPTER	1
108	1347729	SHAFT COLLAR	1
108	1243339	SCREW	1
109	1347728	SHAFT	1
110	1347732	SPRING	1
111	A09026	SCREW	1

Parts List for 37-361 Type 1

Item Number	Part Number	Description	Qty Required
111	000000-00	No Longer Available	1
111	A09027	WASHER	1
111	A09028	WASHER	1
112	1347704	KEY	1
113	1347740	V-BELT A-56	2
114	1347739	PULLEY	1
115	1243336	SCREW	3
116	1347738	RH BEARING COVER	1
117	920040216559	BEARING	2
118	1347737	RH BEARING SUPPORT	1
119	1347743	KNIFE BAR	3
120	1347744	KNIFE SCREW	18
121	37-363	12IN JOINTER KNIFE	3
122	1347742	SPRING	6
123	1347734	CUTTERHEAD	1
123	1347831	CUTTERHEAD ASSY	1
124	1347735	LH BEARING SUPPORT	1
125	920040205348	BEARING	2
126	909478	SCREW	1
126	1347717	LH BEARING NUT	1
126	A09029	WASHER	1
127	1347736	LH BEARING COVER	1
128	1243336	SCREW	3
129	1243339	SCREW	8
130	1243502	WASHER	2
131	1347759	LOCK HANDLE	2
132	A26363	WARNING LABEL	1

Parts List for 37-361 Type 1

Item Number	Part Number	Description	Qty Required
133	1243360	LOCKWASHER	2
133	1246019	CAP SCREW	2
134	1243339	SCREW	2
135	1347747	SHAFT	4
136	1347748	ECCENTRIC BUSHING	8
137	1347745	BASE	1
137	1347835	POINTER	1
137	1246102	FL. WASHER	1
137	1330076	CAP SCREW	1
138	1347750	CLAMP	8
139	1347749	CLAMP PLATE	4
140	1341995	FLAT WASHER	8
141	1243360	LOCKWASHER	8
142	1246198	SCREW	8
143	1347753	HANDLE	2
144	1347752	LEVER	2
145	1347751	SPECIAL COLLAR	4
146	1341945	FLAT WASHER	2
147	1246065	LOCKWASHER	2
148	1243476	NUT	2
149	1347781	HEX HEAD SCREW (CMO)	2
149	1347705	SCREW	2
150	491964-00	NUT	4
150	1243496	NUT-STEEL	4
151	1349529	SCREW	2
151	1347706	SCREW	2
152	1246067	MACH SCREW	2

Parts List for 37-361 Type 1

Item Number	Part Number	Description	Qty Required
153	1347830	SWITCH ARM	1
154	1340100	SWITCH COVER ASSY	1
155	901020100567S	MACHINE SCREW	2
156	402071045007S	SPACER	2
157	438010170101S	SWITCH	1
158	402071115002S	STUD	2
201	1347754	OUTFEED TABLE	1
202	1347756	TABLE LIP	1
203	1243360	LOCKWASHER	4
204	1246052	CAP SCREW	4
205	1347758	SHAFT	4
206	1347755	INFEED TABLE	1
207	1347757	TABLE LIP	1
208	1246052	CAP SCREW	4
209	1243360	LOCKWASHER	4
210	1347726	RABBET LEDGE	1
211	1243561	SCREW	2
212	A26364	DEPTH LABEL	1
213	1246102	FL. WASHER	4
214	1330076	CAP SCREW	4
215	1347762	DUST DEFLECTOR	1
216	1347707	SCREW	2
217	1243496	NUT-STEEL	4
218	1246050	CAP SCREW	2
219	1347760	STOP BLOCK	2
220	1347761	SPRING	2
301	1347771	LOCK HANDLE	1

Parts List for 37-361 Type 1

Item Number	Part Number	Description	Qty Required
302	1341945	FLAT WASHER	1
303	1246066	CAP SCREW	1
304	1243502	WASHER	1
305	1347767	KEY	1
306	1243482	SCREW	1
307	1347769	HAND WHEEL	1
308	1243339	SCREW	1
309	1347768	ADAPTER	1
310	1347764	BRACKET	1
311	1347770	GEAR SHAFT	1
312	1347765	GEAR COLUMN	1
313	1246074	HEX HD CAP SCR	2
314	1243360	LOCKWASHER	2
315	1243502	WASHER	2
316	1347763	FENCE SUPPORT	1
317	1243502	WASHER	2
318	1243561	SCREW	2
319	1243360	LOCKWASHER	2
320	1243555	SCREW	2
321	1246065	LOCKWASHER	2
322	1341945	FLAT WASHER	2
323	1347766	GUARD	1
324	1246013	CAP SCREW	2
325	000000-00	No Longer Available	1
326	491964-00	NUT	1
327	1347772	FENCE BRACKET	1
327	1347825	BLOCK	1

Parts List for 37-361 Type 1

Item Number	Part Number	Description	Qty Required
327	488822-00	FLAT WASHER	1
327	000000-00	No Longer Available	1
328	1347775	LEFT BRACKET	1
329	1330410	ROLL PIN	1
330	1243476	NUT	1
331	000000-00	No Longer Available	2
332	491964-00	NUT	2
333	1347774	PIN	1
334	1347773	SUPPORT	1
335	1347703	KNOB	1
336	1347828	HANDLE ROD	1
337	1243476	NUT	1
338	1347827	FENCE	1
339	1347826	REAR CLAMP	2
340	1347777	HANDLE	1
341	1341945	FLAT WASHER	1
342	1347824	SHAFT	1
343	1246074	HEX HD CAP SCR	4
344	1347776	RIGHT BRACKET	1
344	491964-00	NUT	1
344	000000-00	No Longer Available	1
345	1243339	SCREW	2
856	422301010002	HEX WRENCH	1
856	37-108	JOINTER PUSH BLOCK	1
856	1347832	OPEN-END WRENCH	1
856	1347833	OPEN-END WRENCH	1