





Parts List for 3802L Type 1

Item Number	Part Number	Description	Qty Required
1	901021201711	SCREW	4
2	1347287	M5 PUSH NUT	1
3	1347286	WHEEL	1
4	1347285	BUSHING	1
5	488871-00	LOCK NUT	2
6	1347280	PLATE	1
7	905380	BLADE GUARD	1
8	000000-00	No Longer Available	1
9	1342998	SPRING	1
10	488867-00	CARRIAGE HEAD SCREW	1
11	908601	SCREW	1
12	900983	BLADE FLANGE	1
13	000000-00	No Longer Available	1
14	1347289	GUARD STOP	1
15	000000-00	No Longer Available	1
16	DW3123	32T SAW BLADE	1
17	1347233	INNER BLADE FLANGE	1
18	901010600629	SCREW	1
20	900025	DUST SHROUD	1
21	1347290	SCREW	2
22	488874-00	LOCK WASHER	11
23	905376	UPPER ARM	1
24	900026	ACORN NUT	1
25	000000-00	No Longer Available	2
27	904010101614S	STEEL WASHER	1
29	894410	DUST BAG	1
30	894411	SCREW	1

Parts List for 3802L Type 1

Item Number	Part Number	Description	Qty Required
31	000000-00	No Longer Available	1
32	901010600609S	CAP SCREW	1
33	900566	SPACER	1
34	A07043	BUSHING	1
35	900027	SPRING	1
36	904010312937	WASHER	1
37	1342922	LOCK NUT	1
38	1347266	DEFLECTOR	1
39	901020100559	MACHINE SCREW	1
40	1349622	BLOCK	2
41	1350297S	SCREW	7
42	905371	TOP HANDLE	1
45	1087576	SCREW	2
46	894426	SWITCH COVER	1
47	894427	SWITCH	1
48	905370	BOTTOM HANDLE	1
49	489143-00	WASHER	1
50	000000-00	No Longer Available	1
51	000000-00	No Longer Available	2
52	000000-00	No Longer Available	1
53	894431	STRAIN RELIEF	1
54	491957-00	LOCK WASHER	2
55	901020100501	MACHINE SCREW	2
56	1340622	WASHER	2
57	1310157	SCREW	2
58	000000-00	No Longer Available	1
59	1347291	SCREW	3

Parts List for 3802L Type 1

Item Number	Part Number	Description	Qty Required
61	1243407	RING	1
62	1341834	BEARING	1
63	894449	GEAR HOUSING	1
64	894453	ARBOR BUTTON	1
65	1346716	SCREW	2
66	894452	E-RING	1
67	894454	LOCK PIN	1
68	1348261	SPRING	1
69	1347587	RING	1
70	400081390008	BEARING	1
71	894412	ARMATURE	1
72	1344026	SCREW	2
73	488808-00	LOCK WASHER	2
74	894539	FIELD	1
75	894450	BEARING	1
76	1343267	WAVY WASHER	1
77	894467	MOTOR HOUSING	1
79	1246140	FL WASHER	4
81	894476	SCREW	4
82	1246043	SET SCREW	2
83	1348263	BRUSH HOLDER	2
84	1348266	BRUSH	2
85	1348267	BRUSH CAP	2
100	900030	GUARD LINK ASSY.	1
101	1347250	STOP SCREW	1
102	1246001	MACH SCREW	1
103	1346291	WASHER	1

Parts List for 3802L Type 1

Item Number	Part Number	Description	Qty Required
104	1346290	SPACER	1
105	905379	LINKAGE	1
108	901024531123S	SCREW	1
109	1347296	SPRING PLATE	1
110	894489	LOCK DOWN PIN	1
111	894490	E-RING	1
112	901040800109	SET SCREW	1
113	489026-00	HEX NUT	1
120	900045	HANDLE ASSY.	1
125	900032	PIVOT JOINT	1
126	901020100561S	MACHINE SCREW	1
127	904010101619	STEEL WASHER	1
128	894504	BEVEL GAUGE POINTER	1
129	000000-00	No Longer Available	1
131	000000-00	No Longer Available	1
251	N017151	CORDSET	1
251	N017151	CORDSET	1
257	896316	WRENCH OPEN END	1
258	894554	1/8 HEX WRENCH	1
259	488979-00	WIRE NUT	1
260	000000-00	No Longer Available	1
261	000000-00	No Longer Available	1
262	900024	SLEEVE	1
263	900028	DUST SHIELD	1
264	900029	END CUP	1
265	000000-00	No Longer Available	1
266	900033	CUP	1

Parts List for 3802L Type 1

Item Number	Part Number	Description	Qty Required
267	900034	CUP	1
268	900047	2.5M HEX WRENCH	1
269	894404	RIVET	1
270	905377	GUARD MOUNTING PLATE	1
271	905372	LASER POWER SUPPLY	1
272	908622	LASER	2
273	905373	SWITCH	1
274	905381	LASER GUARD	1
275	000000-00	No Longer Available	1
276	906196	NOSE LABEL R.H.	1
277	906198	NOSE LABEL L.H.	1
278	000000-00	No Longer Available	1
279	906167	SCREW	2
280	489300-00	LOCK NUT	2
281	000000-00	No Longer Available	1
282	887452	DUST SHIELD	1
285	872721	SPRING	2
286	000000-00	No Longer Available	2
287	906166	SET SCREW	2
288	907771	APERTURE LABEL	1
288	908622	LASER	2
288	000000-00	No Longer Available	1
289	488874-00	LOCK WASHER	2
290	904010101614S	STEEL WASHER	10
291	491957-00	LOCK WASHER	4
292	489026-00	HEX NUT	6
293	894496	WRENCH NON ADJUST	1

Parts List for 3802L Type 1

Item Number	Part Number	Description	Qty Required
294	1347293	LOCK NUT	1
295	901020100561S	MACHINE SCREW	10
296	894508	CLAMP LEVER	1
297	894513	WASHER	1
298	894514	FENCE SLIDE	1
299	894515	FENCE SLIDE SUPPORT	1
300	900046	TABLE EXTENSION	1
301	894517	WASHER	4
302	904020101703S	LOCK WASHER	12
304	894519	SCREW	2
305	901051631126S	SCREW	1
306	901051631126S	SCREW	2
307	1346330	CLIP	1
308	904010101610S	STEEL WASHER	1
309	904020101726	LOCK WASHER	3
310	000000-00	No Longer Available	1
311	894541	LEFT FOOT	1
312	894543	FOOT	4
313	901020100504	MACHINE SCREW	4
315	894931	WARNING LABEL	2
316	1347252	WASHER	1
317	488837-00	WARNING LABEL	2
318	908689	BASE	1
319	894587	SPRING SUPPORT	1
320	488822-00	FLAT WASHER	6
321	894575	ROLL PIN	2
322	901010600608	CAP SCREW	6

Parts List for 3802L Type 1

Item Number	Part Number	Description	Qty Required
323	000000-00	No Longer Available	1
324	908690	INDEXING RING	1
325	901020300466	MACHINE SCREW	6
326	1347274	PLATE	1
327	1346269	WEAR PAD	3
328	908692	ROTATING TABLE	1
329	1347259	STOP STUD	1
330	900098	SCALE	1
331	894567	INSERT	1
332	1310016	DR. SCREW	3
333	5140069-51	SCREW	2
334	894570	WASHER	2
335	1347253	MITER POINTER	1
336	894572	PIVOT BOLT	1
337	000000-00	No Longer Available	3
338	000000-00	No Longer Available	1
339	894576	LOCKING SPRING STEEL	1
340	900041	DETENT LEVER	1
341	900042	CAM	1
342	894582	HAT BUSHING	1
343	894583	HANDLE	1
344	894584	HANDLE COVER	1
345	894585	CAP	1
346	000000-00	No Longer Available	2
347	000000-00	No Longer Available	3
348	894589	L. LOCK BAR STRAP	1
349	894590	ADJ. PRESSURE SHOE	1

Parts List for 3802L Type 1

Item Number	Part Number	Description	Qty Required
350	894591	R. LOCK BAR STRAP	1
351	000000-00	No Longer Available	2
352	894593	CAM BAR	1
353	894594	HAT BUSHING	1
354	894595	HANGER	1
355	901020100582	MACHINE SCREW	1
356	894597	EXTENSION SPRING	1
357	894599	WASHER	3
358	000000-00	No Longer Available	1
359	895192	PRESSURE PAD	1
360	895193	WIRE NUT	1
361	895194	SCREW	1
362	895195	SPRING EXTENSION	1
363	000000-00	No Longer Available	1
364	000000-00	No Longer Available	1
365	000000-00	No Longer Available	2
366	000000-00	No Longer Available	2
367	000000-00	No Longer Available	2
368	000000-00	No Longer Available	1
369	000000-00	No Longer Available	1
370	900043	PIN	1
371	900044	SPRING	1
372	900048	GUIDE	1
373	000000-00	No Longer Available	2
374	000000-00	No Longer Available	2
376	A05225	WIRE NUT	1
377	A12715	THERMISTOR	1

Parts List for 3802L Type 1

Item Number	Part Number	Description	Qty Required
380	894521	CLAMP	1
381	904020101726	LOCK WASHER	1
382	5140069-51	SCREW	1
383	904010101610S	STEEL WASHER	1
384	5140010-69	WASHER	1
385	894522	CLAMP LEVER	1
386	894523	PLUNGE ROD	1
387	1346337	SPRING	1
388	1246023	ROLL PIN	1
389	1342915	CUP	1
390	1342944	RUBBER CAP	1
391	1348273	RETAINING RING	1
392	894521	CLAMP	1
393	1346338	SPRING	1
394	1346318	LEVER	1
395	000000-00	No Longer Available	1