



## Parts List for 4210 Type 1

Item Number	Part Number	Description	Qty Required
1	A05213	BASE	1
2	A02550	CLAMPING BAR	1
4	A04258	CLAMPING ROD	1
5	A01344	LEVER	1
6	699409	KNOB	1
7	A04074	CAM	1
8	A02362	SCREW	1
9	A01343	BLOCK	1
10	A02368	PORTER CABLE SCREW	1
11	875509	WASHER	1
12	A01981	SPRING	1
13	A08561	KNOB	1
14	A04096	SCREW	1
15	A01018	WASHER	1
16	A04980	OFFSET GUIDE	1
17	A04981	OFFSET GUIDE	1
18	A02534	SCREW	1
19	A04088	THUMB WHEEL	1
20	699402	KNOB	1
21	A05030	KNOB	1
22	A03781	NUT	1
25	A21132	WARNING LABEL	1
28	A04727	TEMPLET	1
29	A04726	TEMPLET	1
30	A04728	TEMPLET	1
31	A05240	TEMPLET BRACKET	1
32	A04986	BRACKET	1

## Parts List for 4210 Type 1

Item Number	Part Number	Description	Qty Required
33	A03930	BRACKET	1
34	A02026	SCREW	1
35	A21131	NAMEPLATE	1
36	A21135	ID LABEL	1
40	A06478	HEX WRENCH	1
41	698110	ALLEN WRENCH T2	1
856	43743PC	ROUTER BIT	1
856	42046	TEMPLET GUIDE	1
856	42040	TEMPLET GUIDE	1
856	4213	TEMPLET	1
856	5140102-58	TEMPLET	1
856	42054	TEMPLET GUIDE	1
856	000000-00	No Longer Available	1
856	42037	TEMPLET GUIDE	1
856	A04983	OFFSET GUIDE	1
856	A04982	OFFSET GUIDE	1
856	43777PC	ROUTER BIT	1
856	42237	LOCK NUT	1
856	43776PC	ROUTER BIT	1
856	4215	TEMPLET	1