


# Parts Breakdown for JPB-60-1-1/8" and JPB-60-1-1/4"



**Parts List for JPB-60-1-1/8" and JPB-60-1-1/4"**

<b>Index No.</b>	<b>Part No.</b>	<b>Description</b>	<b>Size</b>	<b>Qty.</b>
1	P61119	Oil Plug		1
2	P61111	Back Head		1
3	P91245	Felt Oiler	8.5x25mm	1
4	P91220	Oil Control Plug	1/2"	1
5	P91217	Throttle Lever		1
6	P91250	Spring Pin	4x40mm	1
7	P91252	Stop Lever Spring		1
8	P91251	Stop Lever		1
9	P91218	Throttle Lever Pin	8x30mm	2
10	P91213	Rubber Grip		2
11	P91225	Back Head Nut		4
12	P91224	Lock Washer	5/8"	4
13	P91210	Plunger Spring		1
14	P91209	Plunger		1
15	P61107	Valve Guide		1
16	P61105	Valve Chest		1
17	P91204	Automatic Valve		1
18	P61106	Valve Seat		1
19	P91215	Throttle Valve Stem Guide		1
20	P91212	O-Ring	21.7x3.5mm	1
21	P91214	Throttle Valve		1
22	P91216	Throttle Valve Spring		1
23	P91202	Cylinder Plug		3
24	P91208	Dowel Pin	1/4"x3/4"	1
25	P61101	Cylinder		1
26	P91238	Air Inlet Screen		1
27	P91222	Air Inlet Swivel O-Ring	28.5x2mm	1
28	P91235	Air Inlet Swivel		1
29	P91237	O-Ring	29.4x3.1mm	1
30	P91236	Air Inlet Swivel Nut		1
31	P91246	Plug		1
32	P61123	Back Head Bolt		4
33	P61139	Front Head Bolt		2
34	P91244	Rubber Plug		1
35	P61103	Piston Hammer		1
36	P61126	Tappet Seat		1
37	P61127	Tappet		1
38	P61143	Front Head Bushing	Used w/the JPB-60-1-1/8"	1
	P91243	Front Head Bushing	Used w/the JPB-60-1-1/4"	1
39	P61121	Front Head		1
40	P91242	Front Head Bolt Spring		2
41	P91241	Front Head Bolt Lock Washer		2
42	P91240	Front Head Bolt Nut		2
43	P91229	Steel Retainer Bolt		1
44	P91232	Steel Retainer Bolt Bushing		2
45	P91231	Lock Washer	3/4"	1
46	P91230	Steel Retainer Bolt Nut	3/4"-16	1
47	P91234	Steel Retainer Spring		1
48	P91233	Steel Retainer Plunger		1
49	P91228	Steel Retainer		1