





Parts Breakdown for JPB-60-1-1/8" and JPB-60-1-1/4"



Parts List for JPB-60-1-1/8" and JPB-60-1-1/4"

Index	Part		Description	Size	Qty.
No.	No.				
1	P61119		Oil Plug.....		1
2	P61111		Back Head.....		1
3	P91245		Felt Oiler.....	8.5x25mm	1
4	P91220		Oil Control Plug	1/2"	1
5	P91217		Throttle Lever.....		1
6	P91250		Spring Pin.....	4x40mm	1
7	P91252		Stop Lever Spring		1
8	P91251		Stop Lever		1
9	P91218		Throttle Lever Pin.....	8x30mm	2
10	P91213		Rubber Grip.....		2
11	P91225		Back Head Nut.....		4
12	P91224		Lock Washer	5/8"	4
13	P91210		Plunger Spring		1
14	P91209		Plunger.....		1
15	P61107		Valve Guide.....		1
16	P61105		Valve Chest.....		1
17	P91204		Automatic Valve		1
18	P61106		Valve Seat.....		1
19	P91215		Throttle Valve Stem Guide.....		1
20	P91212		O-Ring.....	21.7x3.5mm	1
21	P91214		Throttle Valve		1
22	P91216		Throttle Valve Spring		1
23	P91202		Cylinder Plug.....		3
24	P91208		Dowel Pin	1/4"x3/4"	1
25	P61101		Cylinder.....		1
26	P91238		Air Inlet Screen		1
27	P91222		Air Inlet Swivel O-Ring	28.5x2mm	1
28	P91235		Air Inlet Swivel		1
29	P91237		O-Ring.....	29.4x3.1mm	1
30	P91236		Air Inlet Swivel Nut		1
31	P91246		Plug		1
32	P61123		Back Head Bolt		4
33	P61139		Front Head Bolt		2
34	P91244		Rubber Plug		1
35	P61103		Piston Hammer		1
36	P61126		Tappet Seat.....		1
37	P61127		Tappet		1
38	P61143		Front Head Bushing	Used w/the JPB-60-1-1/8"	1
	P91243		Front Head Bushing	Used w/the JPB-60-1-1/4"	1
39	P61121		Front Head		1
40	P91242		Front Head Bolt Spring		2
41	P91241		Front Head Bolt Lock Washer.....		2
42	P91240		Front Head Bolt Nut		2
43	P91229		Steel Retainer Bolt		1
44	P91232		Steel Retainer Bolt Bushing		2
45	P91231		Lock Washer	3/4"	1
46	P91230		Steel Retainer Bolt Nut	3/4"-16	1
47	P91234		Steel Retainer Spring		1
48	P91233		Steel Retainer Plunger		1
49	P91228		Steel Retainer		1

Parts Breakdown for JPB-90-1-1/8" and JPB-90-1-1/4"



Parts List for JPB-90-1-1/8" and JPB-90-1-1/4"

Index	Part No.	Description	Size	Qty.
1	P91213	Rubber Grip.....		2
2	P91211	Back Head.....		1
3	P91220	Oil Control Plug.....	1/8"	1
4	P91245	Felt Oiler.....	8.5x25mm.....	1
5	P91217	Throttle Lever.....		1
6	P91250	Spring Pin.....	4x40mm.....	1
7	P91251	Stop Lever.....		1
8	P91252	Stop Lever Spring		1
9	P91218	Throttle Lever Pin.....	8x30mm.....	2
10	P91248	Oil Tank Plug.....	1/2".....	2
11	P91225	Back Head Nut.....		4
12	P91224	Lock Washer	5/8"	4
13	P91219	Oil Plug.....		1
14	P91210	Plunger Spring		1
15	P91209	Plunger.....		1
16	P91208	Dowel Pin.....	1/4"x3/4"	1
17	P91207	Valve Guide.....		1
18	P91205	Valve Chest.....		1
19	P91204	Automatic Valve		1
20	P91206	Valve Seat.....		1
21	P91215	Throttle Valve Stem Guide.....		1
22	P91212	O-Ring.....	21.7x3.5mm	1
23	P91214	Throttle Valve.....		1
24	P91216	Throttle Valve Spring		1
25	P91202	Cylinder Plug.....		5
26	P91201	Cylinder		1
27	P91238	Air Inlet Screen		1
28	P91222	Air Inlet Swivel O-Ring	28.5x2mm	1
29	P91235	Air Inlet Swivel		1
30	P91237	O-Ring.....	29.4x3.1mm	1
31	P91236	Air Inlet Swivel Nut.....		1
32	P91246	Plug		1
33	P91223	Back Head Bolt		4
34	P91239	Front Head Bolt.....		2
35	P91244	Rubber Plug		1
36	P91203	Piston Hammer		1
37	P91226	Tappet Seat.....		1
38	P91227	Tappet		1
39	P61143	Front Head Bushing	Used w/the JPB-90-1-1/8"	1
	P91243	Front Head Bushing	Used w/the JPB-90-1-1/4"	1
40	P91221	Front Head		1
41	P91242	Front Head Bolt Spring		2
42	P91241	Front Head Bolt Lock Washer.....		2
43	P91240	Front Head Nut		2
44	P91229	Steel Retainer Bolt		1
45	P91232	Steel Retainer Bolt Bushing		2
46	P91231	Lock Washer	3/4"	1
47	P91230	Steel Retainer Bolt Nut	3/4"-16	1
48	P91234	Steel Retainer Spring		1
49	P91233	Steel Retainer Plunger		1
50	P91228	Steel Retainer		1