



**IMPORTANT** — To assure product **SAFETY** and **RELIABILITY**, repairs, maintenance or adjustments should be performed by **MAKITA** Service Centers or other qualified service organizations. Always use **MAKITA** replacement parts.

Fig.	Part No.	Qty. Used	Description	Fig.	Part No.	Qty. Used	Description
1	265837-4	7	TAPPING SCREW M3X20	14	226048-6	1	GEAR COMPLETE 13-58
3	415232-0	1	HOUSING SET (WITH FIG. 17)	15	214016-1	1	PLANE BEARING 3
4	265998-0	1	SCREW M5X21	16	411640-3	1	HOLDER 6
6	153155-1	1	GEAR ASS'Y	17	415232-0	1	HOUSING SET (WITH FIG. 3)
7	214017-9	1	PLANE BEARING 5	18	415231-2	1	COVER
8	629651-6	1	DC MOTOR 7.2V (INCL. SPUR GEAR 221851-0)				
10	631160-3	1	CIRCUIT BOARD	<b>ACCESSORIES</b>			
11	678103-4	1	BATTERY	400	763101-2	1	KEYLESS DRILL CHUCK
12	651924-9	1	SWITCH	401	155721-0	1	3-HOUR CHARGER DC7020
13	214016-1	1	PLANE BEARING 3	402	824417-1	1	PLASTIC TOOL CASE