



Item No.	Part No.	Qty. Used	Description	Item No.	Part No.	Qty. Used	Description
1	125102-2	1	SPEED CHANGE LEVER ASS'Y	<p style="text-align: center;"><u>ACCESSORIES</u></p> <p>10 763185-0 1 KEYLESS DRILL CHUCK 10</p> <p>A01 414938-7 2 BATTERY COVER</p> <p>A02 DC1804 1 BATTERY CHARGER</p> <p>A03 784636-0 1 +- BIT 2-65</p> <p>A04 824635-1 1 PLASTIC TOOL CASE (Incl. 1 Ea. Slide Latch Set 186347-7, Makita Label 819143-5)</p> <p>A05 193979-3 1 BATTERY PA09</p>			
2	183793-5	1	HOUSING SET (INC. 14,15)				
4	266130-9	9	TAPPING SCREW BIND PT 3X16				
5	232182-2	1	LEAF SPRING				
6	417283-9	1	F/R CHANGE LEVER				
7	650556-9	1	SWITCH C3NA-1-M1 SINGLE VAR/REV				
8	643909-9	1	BATTERY HOLDER				
9	251468-5	1	- FLAT HEAD SCREW M6X22				
11	125237-9	1	GEAR ASS'Y				
12	629815-2	1	DC MOTOR				
13	911003-8	2	PAN HEAD SCREW M3X6				
14	819001-5	1	MAKITA LABEL				
15	183793-5	1	HOUSING SET (INC. 2,14)				