

:  
:

**ABS 18**  
**71130612942**



				(USD)	AT
0010	31333074016	Motor housing	1		-
0011	31333080002	Holder	1		-
0020	63205034018	Quick-action chuck	1		-
0021	31333059002	Screw	1		-
0030	31333065011	Clutch	1		-
0040	31333061012	Gearbox	1		-
0041	31333060004	Slide switch	1		-
0050	31333068016	Motor	1		-
0060	31333067018	Speed setting switch Set	1		-
0061	31333053001	Toggle switch	1		-
0080	31333070012	Screw Set	1		-
0090	33901115001	Tool case	1		-
0100	31333071011	Handle	1		-
9000	34101029060	Operating instructions	1		-
9010	34151031010	List of spare parts ABS/ASB18	1		-

:  
:

**ABS 18**  
**71130612942**

7 113 06 - ABS 18  
7 104 04 - ASB 18

