

BLK 5.0 (60Hz,220V)



72323100627

				(USD)	AT
0010	32431021007	Cable clamping piece	1		-
0020	43070001006	Screw	2		-
0030	32431040006	Cable clamping piece	1		-
0040	30762224998	Electronics	1		-
0050	41701001172	Grooved ball bearing	1		-
0060	30712088013	Brush holder	2		-
0070	30711132003	Carbon brush	2		-
0080	43070018009	Screw	2		-
0090	31901114014	Motor housing	1		-
0100	53273002236	Armature 50/60Hz230V	1		-
0110	31428118007	Air guide ring	1		-
0120	32416098005	Plate	1		-
0130	32612123008	Sealing ring	1		-
0140	43070007002	Screw	4		-
0150	32901046006	Protective grille	1		-
0200	31506352003	Intermediate bearing	1		-
0290	30610030004	Seal	1		-
0300	31309130002	Housing	1		-
0310	31309087012	Con rod	1		-
0311	41705031001	Needle sleeve	1		-
0320	31309105003	Hollow wheel	1		-
0330	41715047005	Needle cage	1		-
0331	41715043006	Needle cage	1		-
0340	31309089005	Shaft	1		-
0341	31309103001	Cap	1		-
0350	31309090007	Disc	2		-
0360	31309129019	Rotary knob	1		-
0370	31309106015	Cutting head	1		-
0380	31309107000	Die	1		-
0381	43058016058	Cylinder head screw	2		-
0390	31309110004	Punch	1		-
0391	31309111003	Punch guide	1		-
0392	43058015055	Cylinder head screw	2		-
0400	31309085006	Intermediate bearing	1		-
0410	31309086018	Gear-wheel	2		-
0420	40242053007	Pin	1		-
0430	43064019053	Cylinder head screw	4		-
0450	41701210224	Grooved ball bearing	1		-
0480	32805156008	Slide switch	1		-
0490	51273001231	Stator	1		-
0500	43070017001	Screw	2		-
0510	32816055000	Control rod	1		-
0520	32816052004	Control rod	1		-
0530	43041039999	Fillister head screw	2		-
0540	30701285000	Switch	1		-
0550	31201100009	Cover	1		-
0560	31415082004	Pressure piece	1		-
0570	31413007007	Cable grommet	1		-
0580	30707386018	Cable with plug	1		-

: **BLK 5.0 (60Hz,220V)**
: **72323100627**



				(USD)	AT
0600	30240193002	Holder	1		-
0610	43035074085	Cylinder head screw M8X22	1		-
0620	32119032002	Side handle	1		-
5000	62907004005	Allen key SW6	1		-
5010	62907010000	Allen key SW4	1		-
6000	32160003182	Lubricant tube 0,085 kg	1		-
9000	34101100060	Operating instructions	1		-
9010	34151001000	List of spare parts BLK 5.0	1		-
9020	34130054061	Safety instruction	1		-

:
:
:

BLK 5.0 (60Hz,220V)
72323100627

7 232 31 - BLK 5.0

