



861





Parts List for 77240 Type 1

Item Number	Part Number	Description	Qty Required
2	A20730	EXTRUSION	1
3	A20753	WASHER	3
4	A15019	SCREW	3
9	A20891	CAP	1
10	A20892	CAP	1
11	A20786	SCREW	6
14	A20958	INDICATOR	1
16	A20772	BRACKET	1
17	A20771	BRACKET	1
18	A21005	DUST COVER	3
19	A20766	T-NUT	7
21	A16764	THREADED ROD	2
22	A15661	SPRING	4
23	A23157	SPRING RETAINER	4
24	A25277	CLAMP ASSEMBLY	1
27	A21282	SCREW	5
28	A09542	CLAMP BLOCK	4
29	A19168	END CAP	3
30	A09496	SUPPORT	1
31	A09498	SUPPORT	1
32	A20346	WASHER	4
33	A16762	SPACER	4
34	A19153	KNOB	6
37	A21098	DEPTH STOP	1
38	A15081	SCREW	2
40	A20355	SPEC PLATE	1
41	A20373	ID LABEL	1

Parts List for 77240 Type 1

Item Number	Part Number	Description	Qty Required
51	A20972	CLAMP ASSEMBLY	1
54	A20976	CLAMP ASSEMBLY	2
55	A20371	ID LABEL	1
56	A21245	CHIP DEFLECTOR	1
57	A13201	LEFT BRACKET	1
58	A13202	RIGHT BRACKET	1
59	A13510	KNOB	2
60	99361-10	WASHER	4
61	A20457	SCREW	4
62	406-00	NUT	30
63	A12646	HANDLE	2
64	A10659	SCREW	2
65	A20377	INSTRUCTION LABEL	1
66	A20380	WARNING LABEL	1
67	A09356	CLAMPING BAR	1
68	A13111	BAR	1
68	A09357	BAR	1
69	A12722	BRACKET ASSEMBLY	1
69	A10763	BRACKET ASSEMBLY	1
70	A12723	BRACKET ASSEMBLY	1
70	A10766	BRACKET ASSEMBLY	1
71	A13014	FINGER	9
71	A09451	FINGER	13
72	A13015	FINGER	9
72	A09450	FINGER	13
73	A10317	SCREW	70
74	A10316	SQUARE NUT	4

Parts List for 77240 Type 1

Item Number	Part Number	Description	Qty Required
75	A09358	BAR	1
76	A12883	SCREW	2
77	A13515	THUMB SCREW	1
78	A24059	STOP	2
79	5130830-00	FLAT WASHER	2
80	A14169	NUT	6
81	A20238	SCREW	4
82	A20385	INSTRUCTION LABEL	1
82	A20381	INSTRUCTION LABEL	1
83	A20386	INSTRUCTION LABEL	1
83	A20382	INSTRUCTION LABEL	1
84	A13516	THUMB SCREW	1
85	A20387	INSTRUCTION LABEL	1
85	A20383	INSTRUCTION LABEL	1
86	A20388	INSTRUCTION LABEL	1
86	A20384	INSTRUCTION LABEL	1
89	A24499	KNOB	14
90	A13518	THUMB SCREW	4
91	A21708	STOP ASSY.	1
91	A21709	STOP ASSY.	1
91	A20447	STOP ASSY.	1
91	A20448	STOP ASSY.	1
92	A21707	STOP ASSY.	1
92	A21706	STOP ASSY.	1
92	A20499	STOP ASSY.	1
92	A20500	STOP ASSY.	1
92	A20446	STOP ASSY.	1

Parts List for 77240 Type 1

Item Number	Part Number	Description	Qty Required
92	A20445	STOP ASSY.	1
92	A20450	STOP ASSY.	1
92	A20449	STOP ASSY.	1
95	A09354	WEDGE	4
96	A09355	WEDGE	4
97	A12610	HANDLE HALF	2
98	A22839	HANDLE HALF	1
99	A13728	DRIVER	1
100	A15253	WRENCH	1
101	A20957	LOCK NUT	1
104	A20510	INSTRUCTION LABEL	1
105	A20511	LABEL	1
106	A23681	THREADED INSERT	3
107	A25280	SCREW	3
108	A24444	SPRING	2
109	A11251	ROLL PIN	2
110	A13107	FINGER	9
111	A13108	FINGER	9
112	A14002	SQUARE NUT	8
113	A23267	LABEL	1
114	A23268	LABEL	1
115	A23266	INSTRUCTION LABEL	1
116	A15302	THUMB SCREW	1
117	A13842	SCREW	2
118	A13843	RETAINER WASHER	2
119	A20351	DEPTH GAUGE	1
120	A24496	O-RING	2

Parts List for 77240 Type 1

Item Number	Part Number	Description	Qty Required
835	A20467	DVD	1
835	A20466	GUIDE	1
856	430D1PC	ROUTER BIT	1
856	430S1PC	ROUTER BIT	1
856	55169	DEPTH ADJ ASSY	1
856	77241	TEMPLATE	1
861	A22444	STORAGE CASE	1
876	A24746	LABEL SET	1