



Parts List for 77246 Type 1

Item Number	Part Number	Description	Qty Required
27	A21282	SCREW	4
37	A21234	DEPTH STOP	1
62	406-00	NUT	6
67	A09356	CLAMPING BAR	1
68	A13111	BAR	1
69	A12722	BRACKET ASSEMBLY	1
70	A12723	BRACKET ASSEMBLY	1
71	A13014	FINGER	9
72	A13015	FINGER	9
73	A10317	SCREW	40
74	A10316	SQUARE NUT	3
77	A13515	THUMB SCREW	1
78	A24059	STOP	1
79	5130830-00	FLAT WASHER	2
80	A14169	NUT	6
81	A20238	SCREW	4
82	A20385	INSTRUCTION LABEL	1
83	A20386	INSTRUCTION LABEL	1
84	A13516	THUMB SCREW	1
85	A20387	INSTRUCTION LABEL	1
86	A20388	INSTRUCTION LABEL	1
89	A24499	KNOB	2
91	A21709	STOP ASSY.	1
91	A21708	STOP ASSY.	1
92	A21707	STOP ASSY.	1
92	A21706	STOP ASSY.	1
95	A09354	WEDGE	1

Parts List for 77246 Type 1

Item Number	Part Number	Description	Qty Required
96	A09355	WEDGE	1
97	A12610	HANDLE HALF	2
98	A22839	HANDLE HALF	2
110	A13107	FINGER	9
111	A13108	FINGER	9
120	A24496	O-RING	1
835	A20466	GUIDE	1
856	430S1PC	ROUTER BIT	1
856	430D1PC	ROUTER BIT	1