


2 610 907 273
Stand 10-05
Issue J 00-08-10

Fig./Abb. 1



Änderungen vorbehalten
Modifications reserved
Modifications reserves
Salvo modificaciones

Pos.	Part Number	Description	Pos.	Part Number	Description
3	2 610 967 403	Base Plate			
4	2 610 967 404	Rail			
5	2 610 994 284	Guide			
5	2 610 967 405	Guide			
6	2 610 967 406	Pressure Pad			
7	2 610 967 407	Pressure Pad			
8	2 610 967 408	Lever			
9	2 610 967 409	Clamping Plate			
10	2 610 990 519	Indicator			
11	2 610 994 285	Table			
11	2 610 967 411	Table			
12	2 610 967 412	Latch			
13	2 610 967 413	Insert			
14	2 610 967 414	Cover			
15	2 610 967 415	Bracket			
18	2 610 994 286	Strip			
18	2 610 967 418	Strip			
19	2 610 967 419	Cover			
20	2 610 967 420	Cover			
21	2 610 967 421	Screw			
22	2 610 967 422	Screw			
23	2 610 967 423	Nut			
24	2 610 967 424	Collar bolt			
25	2 610 355 278	Screw			
26	2 610 994 274	Screw			
27	2 610 908 270	Washer			
29	2 610 910 779	Washer			
30	2 610 994 275	Trunnion			
31	2 610 907 508	Stud			
33	2 610 358 172	Nut			
34	2 610 355 332	Square Nut			
35	2 610 358 428	Screw			
36	2 610 911 906	Washer			
37	2 610 355 271	Plain Washer			
38	2 610 967 530	Warning Plate			
39	2 610 967 531	Warning Plate			
40	2 610 967 532	Scale			
41	2 610 990 513	Collar bolt			
42	2 610 990 517	Adjusting Nut			
44	2 615 297 329	Washer			
45	2 610 994 276	Spring Lock Washer			
46	2 610 352 518	Screw			
47	2 610 990 528	Knob			
650	2 610 001 643	Hexagon Socket Screw Key			