



## Parts List for 8100 Type 1A

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
2	444262-00	TERMINAL	2
3	49940-00	BRUSH	2
4	000000-00	No Longer Available	1
5	000000-00	No Longer Available	1
6	000000-00	No Longer Available	1
7	000000-00	No Longer Available	1
8	000000-00	No Longer Available	1
9	000000-00	No Longer Available	1
10	000000-00	No Longer Available	1
11	000000-00	No Longer Available	1
12	397589-00	WASHER	1
13	000000-00	No Longer Available	1
14	000000-00	No Longer Available	1
15	406-00	NUT	4
16	000000-00	No Longer Available	1
17	000000-00	No Longer Available	1
18	000000-00	No Longer Available	1
19	381980-00	NUT,STOP	4
20	88782-00	SCREW	4
21	071653-13	SPACER	2
22	000000-00	No Longer Available	2
24	000000-00	No Longer Available	1
25	000000-00	No Longer Available	1
26	000000-00	No Longer Available	1
27	55050-00	PLUG	4
28	037381-00	WASHER	2

## Parts List for 8100 Type 1A

Item Number	Part Number	Description	Qty Required
29	000000-00	No Longer Available	1
30	000000-00	No Longer Available	1
31	383994-00	SWITCH,ON/OFF	1
32	1988-00	SCREW	1
33	849314	TERM	1
34	32114-06	CONNECTOR	1
35	000000-00	No Longer Available	1
36	000000-00	No Longer Available	1
37	000000-00	No Longer Available	1
38	000000-00	No Longer Available	1
39	000000-00	No Longer Available	1
40	000000-00	No Longer Available	1
41	000000-00	No Longer Available	1
42	000000-00	No Longer Available	1
43	000000-00	No Longer Available	1
44	000000-00	No Longer Available	1
45	000000-00	No Longer Available	1
46	000000-00	No Longer Available	1
47	000000-00	No Longer Available	1
48	000000-00	No Longer Available	1
49	234900-01	PLUG 120V 3WIRE	1
50	000000-00	No Longer Available	1
51	9112-00	NUT	1