



Parts List for 8931 Type 1

Item Number	Part Number	Description	Qty Required
56	698709	SPRING	10
62	A22702	CLAMP	1
64	909866	SPINDLE LOCK ACTUATO	1
65	911800	WEAR PLATE	1
66	911801	INSERT	1
67	911751	ROD	1
68	910601	PLUG	1
69	911802	NUT	10
70	908572	HANDLE	1
71	908577	RING	10
72	911803	SCREW	10
73	908576	KNOB	1
75	911809	SCREW	10
76	810425	PLUG	1
77	911776	SCREW	10
78	911804	RETAINING RING	10
79	911796	SPRING	10
81	911797	LEVER	1
82	911710	DISK	1
83	681472	SCREW	10
84	904936	BASE-SUB	1
84	909239	SUB BASE	1
86	802596	SCREW	10
87	862641	NUT	10
88	909242	HANDLE ASSY	1
90	910600	WASHER	10
102	912051	KNOB	1

Parts List for 8931 Type 1

Item Number	Part Number	Description	Qty Required
103	890814	WASHER	10
104	887981	TUBE	1
105	889754	SPRING	10
106	844322	BALL	1
107	910745	ROD	1
108	891797	SPRING	10
109	699400	SPRING GUIDE	1
110	000000-00	No Longer Available	1
112	693953	NUT	10
113	852428	SCREW	10
114	000000-00	No Longer Available	1
117	911177	SPRING	10
118	000000-00	No Longer Available	1
119	699563	SET SCREW	10
120	A02649	BOLT-PLUNGE LOCK	1
120	A02649	BOLT-PLUNGE LOCK	1
121	699552	CLAMP PLUG	1
123	892744	TENSIONER	1
131	000000-00	No Longer Available	1
132	908933	POINTER	1
133	903120	SHAFT	1
134	802417	WASHER	10
135	903114	BUCKLE	1
136	903118	PIN	10
137	903693	NUT	10
138	A00323	WEAR PLATE	1
139	688860	SCREW	10

Parts List for 8931 Type 1

Item Number	Part Number	Description	Qty Required
139	802350	SCREW	10
140	859359	WASHER	10
141	802851	O RING	10
142	888894	SCREW	10
143	890156	KNOB	1
145	000000-00	No Longer Available	1
146	000000-00	No Longer Available	1
148	881290	KNOB	1
160	A22700	BASE HOUSING	1
161	911799	AXLE	1
241	608805-00	VACUUM ADAPTER	1
856	42690	ROUTER EDGE GUIDE	1