


ROUTER

6302
6702
6902
513T6/T7



WARNING: Electrical repairs should only be attempted by trained repairmen. Contact the nearest Porter-Cable Service Center or other competent repair center.

Parts List for 9690 Type ALL TYPES

Item Number	Part Number	Description	Qty Required
1	874588	ARMATURE-220	1
1	903660	ARMATURE	1
1	000000-00	No Longer Available	1
1	682058	ARMATURE 115V	1
1	000000-00	No Longer Available	1
1	683459	ARMATURE 115V	1
1	874299	FAN	1
1	000000-00	No Longer Available	1
1	000000-00	No Longer Available	1
1	000000-00	No Longer Available	1
2	874589	FIELD-220	1
2	000000-00	No Longer Available	1
2	000000-00	No Longer Available	1
2	699326	FIELD	1
2	000000-00	No Longer Available	1
2	694210	FIELD	1
2	803104	LEAD	1
3	N031652	BRUSH	2
3	803483	BRUSH CAP	2
3	873497	BRUSH HOLDER	2
4	842606SV	SWITCH	1
4	876320	SWITCH.	1
5	879758	CORD-EURO	1
5	A11126	CORDSET	1
5	879182	CORD	1
11	855284	BEARING	3
11	878064SV	BEARING	3

Parts List for 9690 Type ALL TYPES

Item Number	Part Number	Description	Qty Required
11	858464	BEARING	3
52	904663	CASE-FRONT	1
52	903967SV	CASING & PINS FRONT	1
52	899192SV	REAR HOUSING	1
52	888727	MOTOR HOUSING CAP	1
60	849314	TERM	1
81	875893	COLLET NUT	1
83	872793	CHUCK	1
83	42999	1/4 INCH COLLET ASSY	1
83	42975	3/8 INCH COLLET ASSY	1
83	42975	3/8 INCH COLLET ASSY	1
83	42950	1/2 INCH COLLET ASSY	1
83	876671	COLLET 1/2 INCH	1
83	876669	COLLET 1/4 INCH	1
83	876670	COLLET 3/8 INCH	1
98	823030	SNAP-RING	10
100	878813	SCREW	10
103	803632	SET-SCREW	10
103	804360	SCREW	10
104	803496	WASHER	10
105	842597	PLUG	1
106	881082	SCREW MACHINE STEEL	10
106	681260	SCREW & WASHER	10
106	838312	SCREW	10
106	863393	SCREW	10
107	802430	LOCKWASHER	10
108	802426	RING	10

Parts List for 9690 Type ALL TYPES

Item Number	Part Number	Description	Qty Required
110	901266	STRAIN RELIEVER	1
111	800835	PIN	10
112	842610	SPRING-PRELOAD	10
113	682063	CONNECTOR VS	1
114	842598	BRACKET SWITCH	1
114	876396	BRACKET	1
115	802764	SCREW	10
117	801374	SCREW	10
120	681260	SCREW & WASHER	10
121	874137	CORD CLAMP	1
122	877817	SCREW	10
223	872998	DEPTH RING	1
225	803674	KNOB	1
225	800995	BASE KNOB	1
226	801821	WASHER	10
227	874582	CLAMP KNOB	1
228	823374	WASHER	10
229	802306	HEX HEAD SCREW	1
230	875807	SUB BASE	1
230	42186	ROUTER SUB-BASE	1
231	874117	SCREW	10
231	688860	SCREW	10
232	685526	SCREW	10
233	5140096-05	SUB BASE	1
233	886264	BASE HOUSING	1
234	800869	SPRING	3
235	42160	ROUTER EDGE GUIDE	1

Parts List for 9690 Type ALL TYPES

Item Number	Part Number	Description	Qty Required
236	803160	SCREW	10
237	882810	KNOB	1
238	824588	ROD GUIDE	1
238	824588	ROD GUIDE	1
239	849314	TERM	1
240	695474	CUTTER SHAFT ASSY	1
241	696696	SCREW	10
856	A22709	OPEN-END WRENCH	1
856	883356	BIT	1
856	A22709	OPEN-END WRENCH	1
856	683157	WRENCH OPEN END	1
856	683157	WRENCH OPEN END	1
861	000000-00	No Longer Available	1
861	000000-00	No Longer Available	1
861	902829	CARRYING CASE	1
861	000000-00	No Longer Available	1