


PORTER-CABLE BATTERY TIGER SAW

Contact the nearest Porter-Cable Service Center or other competent repair center.

307



Parts List for 9837 Type 2

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
4	890316	SWITCH	1
31	D897835	GEAR	1
40	897837	RECIP SHAFT	1
91	893738	COUNTERWEIGHT	1
99	882255	SCREW	10
100	879458	PLATE	1
101	879457	FELT SEAL	1
102	684931	WASHER	10
103	902998	SEAL	1
104	897838	HOUSING	1
105	887348	SCREW	10
106	890335	GUIDE	1
107	693991	RETAINING RING	1
108	858792	WASHER	1
109	861509	BLADE ROLLER	1
110	858779	BEARING	1
112	847564	SNAP RING	1
113	847769	WASHER	10
114	859293	BEARING	1
115	893836	RETAINER	1
116	883485	SCREW	10
117	897834	LOWER HOUSING	1
118	849235	SCREW	10
119	891672SV	SHOE & BRACKET ASSY.	1
120	897774	COLLAR	1
121	648924-00	SPRING	1

Parts List for 9837 Type 2

Item Number	Part Number	Description	Qty Required
122	884696	RETAINER KIT	1
123	648594-00	CLAMP PIN	1
124	897839	HANDLE SET	1
125	893792	SCREW	10
126	895334	BUTTON	1
127	891352	RELEASE BUTTON	1
128	891353	SPRING	1
129	697029	O-RING	1
130	894601	TUBE	1
131	894662	CONTACT PLATE	1
132	895539	CARRYING CASE	1
132	890344	CARRYING CASE	1
133	887712	LATCH CARRYING CASE	1
133	890390	LATCH	1
134	5140070-56	19.2V BATTERY	1
134	5140070-56	19.2V BATTERY	1
135	000000-00	No Longer Available	1
135	903970	SS/A-CHARGER 230V/19	1
135	8924	UNIVERSAL CHARGER	1
135	901562	BATTERY TOP	1
136	8924	UNIVERSAL CHARGER	1
136	000000-00	No Longer Available	1
137	894812	HOUSING	1
137	8924	UNIVERSAL CHARGER	1
138	000000-00	No Longer Available	1
138	894097	CORD	1
139	000000-00	No Longer Available	10

Parts List for 9837 Type 2

Item Number	Part Number	Description	Qty Required
139	861810	SCREW	10
140	000000-00	No Longer Available	1
141	895781	WASHER	10
142	875667	LUBRICANT-4LBS	1
856	689032	CONNECTOR	1