



Model BMR100W Parts List

A = Standard Equipment

○ = Circuit Diagram

Fig.	Part No.	Description	Q'ty	Unit
1	SE00000036	CIRCUIT BOARD A ASS'Y	1	PC.
2	SE09163102	SCREW M3X10	1	PC.
3	SE00000037	CIRCUIT BOARD C ASS'Y	1	PC.
4	SE024PC040	PACKING	1	PC.
5	SE09090011	SCREW 1.7	1	PC.
6	SE020PC020	POWER BUTTON HOLDER	1	PC.
7	SE0310PC5Z	POWER BUTTON	1	PC.
8	SE020PC030	PRESET BUTTON HOLDER	1	PC.
9	SE0312PC5Z	PRESET BUTTON	1	PC.
10	SE09064161	SCREW M4X16	1	PC.
11	SE09163082	SCREW M3X8	1	PC.
12	SE09064161	SCREW M4X16	2	PC.
13	SE00000005	FRONT CABINET ASS'Y	1	PC.
14	SE09163082	SCREW M3X8	1	PC.
15	SE09064161	SCREW M4X16	1	PC.
16	SE0331PC5Z	FRONT BUMPER	1	PC.
17	SE0338PC5Z	FRONT BAR	2	PC.
18	SE09176426	SCREW M6X42	4	PC.
19	SE0313PC5Z	ROTARY KNOB	1	PC.
20	SE21B1110A	ROTARY KNOB RING	1	PC.
21	SE00000042	JACK COVER	1	PC.
22	SE09173106	HEX SCREW M3X10	1	PC.
23	SE0334PC5Z	BATTERY COVER BUMPER	1	PC.
24	SE09176106	HEX SCREW M6X10	2	PC.
25	SE09176106	HEX SCREW M6X10	2	PC.
26	SE024J9070	PACKING	2	PC.
27	SE0333PC5Z	REAR BUMPER	1	PC.
28	SE0340PC5Z	ID LABEL	1	PC.
29	SE00000027	BATTERY COVER (WHITE)	1	PC.
30	SE021PC030	BATTERY COVER LOCKER	1	PC.
31	SE9076146A	HEX SCREW M6X14	1	PC.
32	SE00000028	HANDLE HOLDER R (WHITE)	1	PC.
33	SE0309J96A	HANDLE	1	PC.
34	SE00000029	HANDLE HOLDER L (WHITE)	1	PC.
35	SE9076146A	HEX SCREW M6X14	1	PC.
36	SE09176166	HEX SCREW M6X16	1	PC.
37	SE021J9090	SPRING	2	PC.
38	SE09994007	STEEL BALL	2	PC.
39	SE021J9070	HANDLE SUS-PLATE	1	PC.
40	SE021J9070	HANDLE SUS-PLATE	1	PC.
41	SE09994007	STEEL BALL	2	PC.
42	SE021J9090	SPRING	2	PC.
43	SE09176166	HEX SCREW M6X16	1	PC.
44	SE09153102	SCREW M3X10	2	PC.
45	SE09163062	SCREW M3X6	2	PC.

46	SE021PC000	BATTERY CUSHION	1	PC.
47	SE024PC010	PACKING	1	PC.
48	SE00000030	SPACER (WHITE)	1	PC.
49	SE00000031	BACK UP BATTERY COVER (WHITE)	1	PC.
50	SE021E9010	BATTERY CONTACT (+)	1	PC.
51	SE021E9020	BATTERY CONTACT (-)	1	PC.
52	SE021E9030	+/- BATTERY CONTACT ASS'Y	1	PC.
53	SE09163452	SCREW M3X45	2	PC.
54	SE0308PC5Z	BATTERY COVER LOCKER	1	PC.
55	SE0314PC5Z	LOCKER HINGER	1	PC.
56	SE021PC040	LOCKER FIXER PIN 79.5	1	PC.
57	SE00000033	ROD ANT	1	PC.
58	SE021J9032	ROD ANT HOLDER	1	PC.
59	SE024J9050	PACKING	1	PC.
60	SE021PC050	LOCKER FIXER PIN 63.8	1	PC.
61	SE021PC100	ROD ANT TERMINAL	1	PC.
62	SE021P0020	NUT	1	PC.
63	SE024J9030	PACKING	1	PC.
64	SE01620771	SPEAKER	1	PC.
65	SE09090023	SCREW M4X12	4	PC.
66	SE00000006	SPEAKER NET ASS'Y	1	PC.
67	SE024J9090	PACKING	4	PC.
68	SE024J9070	PACKING	4	PC.
69	SE024J9040	PACKING	4	PC.
70	SE9076146A	HEX SCREW M6X14	4	PC.
71	SE021J9010	SPEAKER HOLDER	1	PC.
72	SE023PC020	EVA 25X18X5.5	1	PC.
73	SE09163102	SCREW M3X10	2	PC.
74	SE023PC000	SPACER	1	PC.
75	GM00000530	BATTERY HOLDER	1	PC.
76	SE09153102	SCREW M3X10	2	PC.
77	SE020PC050	SLIDE BATTERY HOLDER	1	PC.
78	643926-9	BATTERY HOLDER	1	PC.
79	SE09163102	SCREW M3X10	2	PC.
80	SE020PC040	CLUSTER BATTERY HOLDER	1	PC.
81	SE023PC020	EVA 25X18X5.5	1	PC.
82	SE02311000	SPACER (A)	1	PC.
83	SE021J9010	SPEAKER HOLDER	1	PC.
84	SE024J9030	PACKING	1	PC.
85	SE09163452	SCREW M3X45	2	PC.
86	SE00000032	BACK COVER (WHITE)	1	PC.
87	SE01620771	SPEAKER	1	PC.
88	SE09090023	SCREW M4X12	4	PC.
89	SE00000006	SPEAKER NET ASS'Y	1	PC.
90	SE024J9090	PACKING	4	PC.
91	SE024J9070	PACKING	4	PC.
92	SE024J9040	PACKING	4	PC.
93	SE9076146A	HEX SCREW M6X14	4	PC.
A01	SE00000015	AC ADAPTER	1	PC.