



Torque for fasteners to be 28-33 IN/LBS unless otherwise noted.



BT50B
BRAD NAILER
CLAVADORAS DE PUNTILLA
CLOUEURS



Parts List for BT50B-2 Type 0

Item Number	Part Number	Description	Qty Required
1	100297	SCREW	1
2	S32030	WASHER- SPECIAL	1
3	S32032	COVER-EXHAUST	1
4	S32045	MUFFLER	1
5	100260	SCREW	7
6	S32186	WASHER- SPECIAL	6
7	T32055	CAP	1
8	S32011	INSERT-M4	4
9	T32007	BUMPER- PISTON STOP	1
10	T32028	SPRING-HEAD VALVE	1
11	108572	O-RING-26MMX2MM	1
12	9R198720	HEAD VALVE	1
13	108573	O-RING-1.378X.079	1
14	S32109	RING-PISTON	1
15	101155	ASSEMBLY-DRIVER/PIST	1
16	T32031	SEAL-CYLINDER SLEEVE	1
17	S32209	SLEEVE-CYLINDER	1
18	RG161210	O-RING-1.612X.103 NB	1
19	T32080	CHECK SEAL	1
20	100353	O-RING-1.301X.070	1
21	102882	BUMPER	1
22	S32187	PLATE- FRAME	1
23	S32001	WASHER- URETHANE ORA	1
24	S32090	GUIDE-DRIVER	1
25	T32046	GASKET-FRAME/CAP	1
26	T32008A	FRAME	1
27	113218	LABEL-BOSTITCH	1

Parts List for BT50B-2 Type 0

Item Number	Part Number	Description	Qty Required
28	106173	STOP-TRIGGER	1
29	100298	PIN-SPIRAL M3X30	1
30	102549	PIN-SPECIAL SPIROL M	1
31	S32141	GASKET- END CAP	1
32	S32140	CAP-END	1
33	S32017A	ASSEMBLY-NUT PLATE	1
34	101685	NOSE	1
35	S32182	COVER-NOSE	1
36	S32184	SPACER	4
37	100258	SCREW	2
39	S32121	GUARD-ARM	1
40	MHE4070-100	ELASTIC STOP NUT-M4	1
41	101963	NOSE-50MM TRIP	1
42	S32122A	ASSEMBLY-ARM GUIDE	1
43	S32179	CONTACT- LOWER ARM	1
44	S32127	ARM-UPPER CONTACT	1
45	T27160	SPRING-COMPRESSION	1
46	104965	CASTING PLATE	1
47	103163	MAGAZINE	1
48	159911	LABEL-WARNING-CT/ST	1
49	159914	LABEL-WARNING-T.O.	1
50	103946	LABEL-BT50B MAG. CAP	1
51	101696	ROD-WEAR	1
52	102941	END-MAGAZINE	1
53	MSC4070-10	SCREW-SHCS-M4X0.70X1	7
54	101692	BRACKET-MAGAZINE	1
55	100222	PIN-SPRING	2

Parts List for BT50B-2 Type 0

Item Number	Part Number	Description	Qty Required
56	101690	LATCH	1
57	S32024	SPRING-COMPRESSION	1
58	101691	BRACKET-FRAME LATCH	1
59	S32066	PIN-SPECIAL	1
60	103425	ASSEMBLY-LATCH BRACK	1
61	S32176	PIN-SPECIAL	1
62	101738	ROD-MAGAZINE	1
63	102812	RING-CYLINDER SLEEVE	1
65	101695	BUSHING-PUSHER	1
66	102867	PUSHER	1
67	101688	SPRING-COMPRESSION	1
68	100817	O-RING-1.299X.103	1
69	103080	MAGAZINE-FIXED	1
70	TVA5	TRIGGER VLV KIT	1
71	106967	O-RING-.724X.106	1
72	86459	O-RING	1
73	CNTK2	KIT-CONTACT TRIP CON	1
74	SEQ6	KIT-SEQUENTIAL	1
75	DTK1	KIT-DUAL TRIGGER	1
76	102388	SCREW-SFHCS M4X0.07X	1
78	103386	ASSEMBLY-CORE PLATE	1
79	UB2104.6	PIN- SPRING .094 X .	1
80	105235	SCREW-SHCS M4X25	1
800	100679	LUBE (1LB.CAN)	1
800	100653	LUBE (2CC)	1
876	ORK10	REPAIR KIT	1
876	RBK14	BT35/50 S32/PC5000 K	1