



Parts List for BV2200-B3 Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|------------------|--------------|
| 1 | 5140057-32 | CONNECTOR | 1 |
| 2 | 5140057-33 | SOFT JACKET | 1 |
| 3 | 5140057-34 | SWITCH ACTUATOR | 1 |
| 4 | 5140057-35 | SWITCH ASSEMBLY | 1 |
| 5 | 5140057-36 | SPEED CONTROL | 1 |
| 6 | 5140057-37 | CAPACITOR | 1 |
| 7 | 5140057-38 | BELT | 1 |
| 8 | 5140057-39 | RIGHT HOUSING | 1 |
| 9 | 5140057-40 | RIGHT HOUSING | 1 |
| 10 | 5140057-41 | FRONT TUBE ASSY. | 1 |
| 11 | 5140057-42 | REAR TUBE ASSY. | 1 |
| 12 | 5140057-43 | AXLE | 1 |
| 13 | 5140057-44 | WHEEL ASSY. | 2 |
| 14 | 5140057-45 | LOCK ASSY | 1 |
| 15 | 5140057-70 | MOTOR ASSY. | 1 |
| 15 | 5140062-04 | BRUSH | 2 |
| 15 | 5140062-05 | BRUSH HOLDER | 2 |
| 16 | 5140057-47 | WASHER | 1 |
| 17 | 5140057-48 | FAN | 1 |
| 18 | 5140057-49 | LOCK NUT | 1 |
| 19 | 5140057-50 | COVER | 1 |
| 20 | 5140057-68 | POWER CORD | 1 |
| 21 | 5140057-52 | CORD PROTECTOR | 1 |
| 22 | 5140057-53 | SCREW | 33 |
| 23 | 5140057-54 | HOUSING,LEFT | 1 |
| 24 | 5140057-55 | SWITCH ASSEMBLY | 2 |
| 25 | 5140057-56 | KNOB,SELECTOR | 1 |

Parts List for BV2200-B3 Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|-------------------|--------------|
| 26 | 5140057-57 | HOUSING,LEFT | 1 |
| 27 | 5140057-58 | DEFLECTOR | 1 |
| 28 | 5140057-59 | SCREW | 1 |
| 29 | 5140057-60 | DUST OUTLET | 1 |
| 30 | 5140057-61 | DUST BAG ASSEMBLY | 1 |
| 31 | 5140057-62 | RUBBER WASHER | 2 |