



Parts List for CCS818 Type 1

Item Number	Part Number	Description	Qty Required
1	330019-03	SCREW	18
2	330019-05	SCREW,PLASTITE	1
3	622895-00	SPROCKET	1
4	623963-00	CLAMP	1
5	623964-00	SCREW	1
6	624334-00	SCREW	2
7	624521-00	RETAINING RING	1
8	000000-00	No Longer Available	1
9	90502128	ACTUATOR	1
10	90502132	GUARD	1
11	90502134	BAR	1
12	90502135	COVER	1
13	90502136	SPRING	1
14	90502137	SPRING, TRIGGER	1
15	90502141	CLAMP	1
16	90502142	CHAIN COVER	1
17	90502143	CLIP	1
18	90502145	TRANSMISSION	1
19	90502171	OIL BOTTLE ASSY.	1
20	90502469	SCREW	5
21	90502712	CLAMSHELL	1
22	90502720	SWITCH	1
23	90502723	HEX WRENCH	1
24	90502764	HANDLE	1
25	90504642	OIL SEAL	1
26	90506375	BAR ASSY	1
27	623382-00	CHAIN	1

Parts List for CCS818 Type 1

Item Number	Part Number	Description	Qty Required
28	623381-00	BAR	1
29	624732-00	SHEATH	1
30	5103536-00	SWITCH	1
31	90519433	WAVY WASHER	1
866	90506197	BATTERY PACK	1
867	5102026-00	BATTERY CAP	1
871	5103069-12	CHARGER	1