



Parts List for CD18SRK-2 Type 2

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|---------------------|--------------|
| 2 | 000000-00 | No Longer Available | 1 |
| 3 | 5101240-00 | SPRING PIN | 1 |
| 4 | 148354-03 | BIT CLIP | 1 |
| 5 | 311978-01 | F/R ACTUATOR | 1 |
| 6 | 311993-00 | SCREW | 6 |
| 7 | 498511-00 | SCREW | 1 |
| 8 | 5103416-02 | TRANSMISSION | 1 |
| 9 | 5102586-10 | VSR SWITCH (DC) | 1 |
| 14 | 000000-00 | No Longer Available | 1 |
| 15 | 5102763-02 | MOTOR & PINION | 1 |
| 16 | 5102589-15 | NAMEPLATE | 1 |
| 17 | 5102537-01 | ID LABEL | 1 |
| 19 | 5103587-00 | BIT HOLDER ASSY | 1 |
| 20 | 497927-02 | RETAINING CLIP | 1 |
| 21 | 497935-02 | BEARING WASHER | 1 |
| 22 | 5100115-00 | BIT RELEASE RING | 1 |
| 23 | 5100976-00 | TERMINAL BLOCK | 1 |
| 24 | 5100117-00 | SPRING | 1 |
| 25 | 5100035-01 | SPRING | 2 |
| 26 | 5100776-00 | HUB CAP | 1 |
| 27 | 5101752-00 | WASHER | 1 |
| 28 | 5102929-00 | INSULATOR | 2 |
| 856 | 71-399 | MAG.BIT TIP HOLDER | 1 |
| 861 | 499124-13 | KIT BOX | 1 |
| 866 | HPB18 | BATTERY | 2 |
| 867 | 5102026-00 | BATTERY CAP | 2 |
| 871 | 5103069-10 | CHARGER | 1 |

Parts List for CD18SRK-2 Type 2

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|-------------|--------------|
| 871 | 5103069-12 | CHARGER | 1 |