



Parts List for CST1000 Type 4

Item Number	Part Number	Description	Qty Required
101	000000-00	No Longer Available	1
102	000000-00	No Longer Available	1
103	243729-02	HANDLE CLAMSHEL	1
104	90552860	SWITCH	1
106	371406-02	TRIGGER	1
107	000000-00	No Longer Available	1
108	371407-03	LOCK-OFF BUTTON	1
110	000000-00	No Longer Available	1
111	5103541-00	SCREW	16
112	243723-00	WARNING LABEL	1
113	264734-00	BRAND LABEL	1
118	371411-00	BATTERY	1
120	243725-00	CLAMSHELL,BAT.	1
123	372036-02	BUTTON	1
124	000000-00	No Longer Available	1
125	243732-00	KNOB ASSY.	1
128	243538-01	TUBE	1
131	242885-01	SPOOL & LINE	1
131	AF-100	REPLACEMENT SPOOL	1
132	806474-00	LEVER	1
133	385022-03	COVER	1
136	243726-00	EDGE GUIDE	1
157	90517269	CHARGER	1
159	372057-00	MOUNT	1
162	000000-00	No Longer Available	1
163	000000-00	No Longer Available	1
166	000000-00	No Longer Available	1

Parts List for CST1000 Type 4

Item Number	Part Number	Description	Qty Required
167	821057-00	SCREW	2
171	371803-00	SCREW	1
173	243431-00	LABEL	1
174	000000-00	No Longer Available	1
800	000000-00	No Longer Available	1
802	242973-02	COLLAR	1
803	000000-00	No Longer Available	1
846	243457-00SV	HARDWARE BAG	1