



Parts List for CT224-AR Type 1

Item Number	Part Number	Description	Qty Required
1	5140096-10	TANK ASSEMBLY	1
2	5140096-11	NUT	10
3	5140096-12	SPRING WASHER	11
4	5140096-13	FLAT WASHER	16
5	5140096-14	WHEEL ASSY.	2
6	5140096-15	SCREW	2
7	5140096-16	PLUG	2
8	5140096-17	TUBE ASSY	1
9	5140096-18	SPRING WASHER	4
10	5140096-19	CLAPBOARD	2
11	5140096-20	FRONT HOUSING	1
12	5140096-21	FAN	1
13	5140096-22	REAR MOTOR COVER	1
14	5140096-23	WAVY WASHER	1
15	5140096-24	BEARING	1
16	5140096-25	SCREW	4
17	5140096-26	STATOR ASSY.	1
18	5140096-27	ROTOR ASSY.	1
19	5140096-28	CAPACITOR	1
20	5140096-29	WASHER	1
21	5140096-30	SCREW	4
22	5140096-31	BEARING	1
23	5140096-32	LIP SEAL	1
24	5140096-33	BOLT	1
25	5140096-34	CRANK CASE	1
26	5140096-35	CRANK	1
27	5140096-36	SCREW	1

Parts List for CT224-AR Type 1

Item Number	Part Number	Description	Qty Required
28	5140096-37	CRANKCASE GASKET	1
29	5140096-38	BREATHER ASSY.	1
30	5140096-39	CRANKCASE COVER	1
31	5140096-40	OIL LEVELER	1
32	5140096-30	SCREW	6
33	5140096-42	HANDLE	1
34	5140096-43	CYLINDER GASKET	1
35	5140096-44	CONNECTING ROD	1
36	5140096-45	PISTON	1
37	5140096-46	OIL RING	1
38	5140096-47	SEAL RING	2
39	5140096-48	CYLINDER	1
40	5140096-49	GASKET VALVE PLATE	1
41	5140096-50	ELBOW	1
42	5140096-51	SCREW	4
43	5140096-52	AIR FILTER ASSY.	1
44	5140096-53	CYLINDER HEAD	1
45	5140096-54	CYLINDER GASKET	1
46	5140096-55	VALVE PLATE ASSEMBLY	1
47	5140096-56	LOCATING PIN	1
48	5140096-57	VALVE AIR	1
49	5140096-58	CIRCLIP	1
50	5140096-59	PISTON PIN	1
51	5140096-60	LOCKING NUT	1
52	5140096-61	SAFETY VALVE	1
53	5140096-62	PRESSURE SWITCH	1
54	5140096-63	CONNECTOR	1

Parts List for CT224-AR Type 1

Item Number	Part Number	Description	Qty Required
55	5140096-64	REGULATOR	1
56	5140096-65	VALVE ASSY	1
57	5140096-66	PRESSURE GAUGE	1
58	5140096-67	PRESSURE GAUGE	1
59	5140096-68	BOLT	4
60	5140096-69	DISCHARGE TUBE	1
61	5140096-70	CHECK VALVE	1
62	5140096-71	CORDSET	1
63	5140096-72	DRAIN VALVE	1
64	5140096-73	FOOT SUPPORT	1
65	5140096-74	FLAT WASHER	1
66	5140096-75	BOLT	1
67	5140096-76	CIRCLIP	1
68	5140096-77	FLAT WASHER	2
69	5140096-30	SCREW	2
70	5140096-79	SCREW	2
71	5140096-80	SCREW	9
72	5140096-81	REAR HOUSING	1
73	5140096-82	BOARD	1
74	5140096-83	O-RING	1