





Parts List for DC222KA Type 1

Item Number	Part Number	Description	Qty Required
101	323489-00	CAP	1
102	579212-00	RING	1
103	577928-00	TUBE	1
104	583890-00	BALL	1
105	578387-00	WASHER	1
106	871690	SPRING	1
107	590306-00	FELT SEAL	1
110	574937-01	GEAR CASE COVER	1
111	490785-00	SLEEVE	1
112	575023-00	SELECTOR	1
113	324006-16	SCREW	1
114	478843-00	SPRING	1
115	575026-00	CAP	1
116	575024-00	RELEASE BUTTON	1
120	N088740	CLAMSHELL ASSY.	1
121	330065-08	SCREW	21
122	578218-00	SLIDER	1
123	575030-00	SPRING	1
124	575032-00	PIN	2
125	479313-00	SPRING	1
126	1007577-01	HANDLE & COVER	1
127	1005987-00	LEVER ASSEMBLY	1
128	493678-00	SWITCH	1
129	1006234-00	HANDLE COVER	1
131	495610-00	LEAD,BROWN	1
132	495610-01	LEAD,BLACK	1
140	930026-01	BUMPER	1

Parts List for DC222KA Type 1

Item Number	Part Number	Description	Qty Required
141	489874-00	SPRING	1
142	487086-00	KNOB	1
145	575177-00	RELEASE BUTTON	2
146	590240-00	SPRING	2
147	N013763	BLOCK KIT	1
148	N013763	BLOCK KIT	2
149	638529-00	TERMINAL BLOCK	1
160	493687-00	SIDE HANDLE ASY	1
170	580787-00	DEPTH STOP	1
201	492807-00	SPINDLE	1
202	323711-02	O RING	1
203	492808-00	BEAT PIECE	1
204	492809-00	GUIDE BUSHING	1
205	870890-00	RING,RETAINING	1
206	327087-00	WASHER	1
207	323762-07	RING	1
210	590302-00	NEEDLE BEARING	1
211	488105-00	CLIP	1
212	589350-00	WASHER	1
213	589346-00	SPRING	1
214	492817-00	BUSH	1
215	N071966	REPAIR KIT	1
216	479478-00	BEARING	1
217	589348-00	WASHER	1
218	488390-00	CLIP	1
219	491536-00	O-RING	1
220	492821-00	HOUSING	1

Parts List for DC222KA Type 1

Item Number	Part Number	Description	Qty Required
221	478909-00	SEAL	1
222	492830-00	RAM	1
223	577168-00	O RING	1
224	492822-00	PISTON	1
225	494317-00	WASHER	1
226	490286-00	SPRING	1
227	492823-00	BALL SPINDLE	1
228	492824-00	CRANKSHAFT	1
229	N071966	REPAIR KIT	1
230	477133-00	BALL BEARING	2
240	575021-00	COMPR. SPRING	1
241	492826-00	COLLAR	1
242	323763-10	SNAP RING	1
243	492828-00	GEAR	1
244	330003-40	BEARING,BALL	1
245	492827-00	GEAR	1
246	575022-00	PLATE	1
247	590312-00	PIN	1
250	493673-00	MOTOR & PINION	1
251	582865-00	FILTER	1
252	323711-34	RING,O	1
253	478898-00	LEVER ASSEMBLY	1
254	577802-00	SHIM WASHER	1
255	490129-00	SCREW	2
260	603754-01	BRUSH BOX	2
800	870889-03	GREASE	2
801	487130-04	GREASE	1

Parts List for DC222KA Type 1

Item Number	Part Number	Description	Qty Required
818	493152-01	LABEL	1
821	000000-00	No Longer Available	1
846	492804-00	SERVICE KIT	1
861	574931-20	KIT BOX	1
866	DW0242	BATTERY, 24V	2
871	DW0246	24V CHARGER	1