



Parts List for DC411KA Type 1

Item Number	Part Number	Description	Qty Required
1	640879-00	CLAMSHELL SET	1
2	652479-00SV	ARMATURE ASSEMBLY	1
3	330003-60	BEARING	2
4	623564-00	PINION	1
5	604484-00	NUT	1
6	631563-00	BOOT	1
7	610107-00	BEARING SUPPORT	1
8	623617-00	FELT SEAL	1
9	640579-00	FAN BAFFLE	1
10	623580-00	BRG. RETAINER	1
11	623586-00SV	GEAR CASE ASSY.	1
12	625414-00	GEAR CASE COVER	1
13	623618-00	GASKET	1
14	330065-13	SCREW	4
15	385676-01	SCREW	4
16	646976-00	BUTTON,LOCK-OFF	1
17	653739-00	NAMEPLATE	1
18	646006-00	LABEL, ID	1
19	650920-01	SWITCH ASSEMBLY	1
20	611202-00SV	MAGNET RING	1
21	643772-00	GUARD	1
21	397661-01	GUARD	1
22	631609-00	SCREW	1
23	633257-00SV	BACKING FLANGE	1
24	636226-00	NUT	1
25	330019-25	SCREW,THD.FORM	2
26	330019-04	SCREW,PLASTITE	6

Parts List for DC411KA Type 1

Item Number	Part Number	Description	Qty Required
30	610126-00	BRUSH BOX	2
31	659067-00	LABEL-WARNING (SPANI	1
87	401680-00	WRENCH	1
88	149142-00	HANDLE,SIDE	1
92	633044-00	O-RING	1
93	633043-00	O-RING	1
800	761995-01	GREASE, 6 OZ.	1
800	283484-01	GREASE,32 OZ.	1
856	651278-09	GRINDING WHEEL	1
862	624807-01	TOOL BAG	1
866	DC9096	BATTERY PACK	2
871	388683-12	1 HOUR CHARGER	1