



## Parts List for DC500K Type 1

Item Number	Part Number	Description	Qty Required
1	5140017-01	TOP COVER	1
2	596452-08	ADAPTER	1
3	5140017-03	SCREW	2
4	5140017-04	HANDLE,LOWER	1
5	5140017-05	HANDLE,UPPER	1
6	5140017-06	BATTERY LATCH ASSY.	1
7	5140017-07	ACCESSORY BRACKET	1
8	5140017-08	BELT HOOK	1
9	5140057-00	SERVICE KIT	1
10	5140057-00	SERVICE KIT	1
11	5140017-11	MOTOR ASSEMBLY	1
12	5140017-12	HOSE ASSY.	1
13	5140017-13	LATCH ASSY 2PK	1
14	5140017-14	TERMINAL ASSY.	1
15	5140017-15	MOTOR HOUSING	1
16	5140017-16	COVER,BASE	1
17	5140017-17	TANK ASSEMBLY	1
18	5140017-18	DRAIN PLUG	1
19	5140017-19	WIRE & FUSE ASSY.	1
20	5140017-20	FAN ASSEMBLY	1
21	5140017-21	CREVICE TOOL	1
22	5140017-22	UTILITY NOZZLE	1
23	5140017-23	CORD BUSHING	1
24	5140017-24	CORD HOLDER	2
25	5140017-25	BALL	1
26	5140017-26	AC-DC CONVERTER	1
27	5140017-27	DC CONVERTER	1

## Parts List for DC500K Type 1

Item Number	Part Number	Description	Qty Required
28	5140058-09	POWER SWITCH	1
29	5140017-29	POWER CORD	1
30	5140017-30	SCREW, M4X10L	8
31	617504-00	NAMEPLATE	1
32	5140017-32	FLOAT CAGE	1
33	5140017-33	PREFILTER	1
34	5140017-30	SCREW, M4X10L	2
35	5140017-35	CLIP,CORD	1
36	5140058-09	POWER SWITCH	1
37	5140017-37	SLEEVE	1
38	5140017-38	SCREW,M4	1
856	DC5001H	FILTER	1
866	DC9096	BATTERY PACK	1
867	645221-00	BATTERY CAP	1
871	388683-12	1 HOUR CHARGER	1