



## Parts List for DC527 Type 1

Item Number	Part Number	Description	Qty Required
1	5140057-01	HANDLE ASSEMBLY	1
2	5140060-17	FLUORESCENT BULB	1
3	5140027-35	TOP HOUSING ASSY	1
866	DC9096	BATTERY PACK	1
867	645221-00	BATTERY CAP	1
871	388683-12	1 HOUR CHARGER	1