



## Parts List for DC800KL Type 1

Item Number	Part Number	Description	Qty Required
1	633412-00	CLAMSHELL SET	1
2	637843-00	ID LABEL	1
3	330019-04	SCREW,PLASTITE	8
4	611202-00SV	MAGNET RING	1
5	610552-00SV	SWITCH ASSY.	1
6	636747-00	WIRE HARNESS	1
9	610023-00	IMPACTOR	1
10	615803-00SV	BARREL	1
11	615801-00SV	ANVIL ASSY.	1
12	610542-00	O-RING	1
13	610539-00	THRUST WASHER	1
14	648605-00	RING GEAR	1
15	610545-00	PLANET GEAR	3
16	611316-00	ROLLER PIN	3
17	611488-00	WASHER	1
19	330019-06	SCREW	4
20	637845-00	NAMEPLATE	1
21	610544-00	CARRIER	1
22	5190-00	BALL	2
23	613461-00	SPRING	1
24	613724-00	THRUST WASHER	2
25	610541-00	THRUST BEARING	1
26	N020802	DETENT PIN	1
27	99205-07	PIN,ROLL	1
28	038769-00	SPRING	1
29	611200-06	ARMATURE ASSY.	1
30	391032-00	BEARING & BOOT	1

## Parts List for DC800KL Type 1

Item Number	Part Number	Description	Qty Required
31	330003-63	BALL BEARING	1
32	330003-12	BEARING,BALL	1
33	330019-49	SCREW,PLASTIC	4
34	330019-25	SCREW,THD.FORM	2
35	610126-00	BRUSH BOX	2
36	610550-00	FAN BAFFLE	1
37	611205-00	GEARCASE	1
38	610107-00	BEARING SUPPORT	1
800	286436-00	GREASE	1
800	284778-00	GREASE,MOLYKOTE	1
861	637475-00	LATCH ASSEMBLY	1
861	380865-02	KIT,HANDLE	1
861	633094-00	KIT BOX	1
866	DC9360	BATTERY PACK	1
871	DC9000	CHARGER	1