



Parts List for DCD710S2 Type 3

Item Number	Part Number	Description	Qty Required
1	N302781	HOUSING ASSEMBLY	1
2	N034293	ADJUST COLLAR	1
3	N383057	CHUCK,10MM	1
5	N383058	TRANSMISSION ASSY.	1
6	N037108	SHIFTER WIRE	1
7	N037111	SHIFTER ASSEMBLY	1
8	N382748	MOTOR & SWITCH ASSY.	1
10	N017247	FWD/REV BUTTON	1
11	326467-00	DETENT	1
12	N329340	SCREW	9
13	N092854	CHUCK SCREW	1
15	N031603	RUBBER PLUG	2
20	N073447	LABEL LOGO	1
22	N073390	LABEL-WARNING (SPANI	1
30	N068674	BELT HOOK	1
856	DW2002 Z	#2 PHILLIPS BIT TIP	1
862	N041318	TOOL BAG	1
871	DCB100	CHARGER	1