



Parts List for DCD930KX-B2 Type 2

Item Number	Part Number	Description	Qty Required
22	586200-10	KEYLESS CHUCK	1
23	605256-01	SCREW	1
24	652378-00	RETAINING PLATE	1
25	650470-00	LOCK RING	1
26	652379-00	ANVIL	1
27	654110-00	PIN	5
42	N016695SV	CLAMSHELL SET	1
43	N020621SV	SWITCH-V.S.R.	1
45	N161059	ARMATURE ASSEMBLY	1
46	648124-00	MAGNET RING	1
47	N007948	BEARING CAP	2
48	N091392	F/R BUTTON	1
49	N031214	BRUSH BOX SET	1
50	148354-03	BIT CLIP	1
51	N028034	ID LABEL	1
52	682211-00	SCREW,TORX	13
53	330019-52	SCREW PLASTITE	4
54	N014681	DETENT SPRING	2
56	650421-00	SIDE HANDLE	1
61	N120429SV	GEARCASE ASSY	1
61	N211312	GEARCASE ASSY	1
70	N119986	NAME PLATE	1
800	N017298	GREASE	1
800	429698-00	GREASE:4 LB CAN	1
836	559662-99	MANDREL	1
836	596004-99	INSERT	1
836	233804-40	CHUCK REMOVAL FIXTURE	1

Parts List for DCD930KX-B2 Type 2

Item Number	Part Number	Description	Qty Required
836	233947-00	HOLDING FIXTURE	1
861	660141-00	KITBOX	1
866	615824-12	BATTERY PACK	1
867	645221-00	BATTERY CAP	1
871	DW9116-B2	CHARGER	1