



### Parts List for DCS393 Type 3

Item Number	Part Number	Description	Qty Required
1	N064324	CLAMSHELL SET	1
2	N054423	MOTOR COVER	1
3	N173219	END CAP	1
4	330019-04	SCREW,PLASTITE	8
5	398987-00	SCREW	4
6	N094669	ID LABEL	1
7	098000-11	WRENCH	1
8	N092315	SWITCH ASSEMBLY	1
9	605107-00	LOCK-OFF BUTTON	1
10	330019-40	SCREW	1
11	389120-00	SPRING	1
12	388531-00	PIN	1
14	659417-00SV	SPINDLE ASSEMBLY	1
15	605081-01	GASKET	1
16	613783-00	SCREW	8
17	605094-00	RUBBER WIPER	1
18	629444-00	SPINDLE LOCK	1
19	058698-00	SPRING	1
20	N086834	UPPER GUARD	1
21	389132-00	BUMPER	1
22	610134-00	SCREW,SHOULDER	1
23	614048-00	SPIRAL PIN	1
24	611925-00	LOWER GUARD	1
25	N035365	TORSION SPRING	1
26	150383-00	RING,RETAINING	1
27	N062190	SHOE ASSEMBLY	1
28	605105-00	LEVER	1

### Parts List for DCS393 Type 3

Item Number	Part Number	Description	Qty Required
29	618901-00	SHAFT	1
30	330045-14	SCREW, TAPTITE	1
31	N112241	PLAIN WASHER	1
32	098128-85	CARRIAGE BOLT	1
33	395889-00	KNOB	1
34	N022876	CARRIAGE BOLT	1
35	381069-00	SET SCREW	1
36	058287-00	SPRING	1
37	396992-02	KNOB	1
38	650109-00	CLMP WASHER IN	1
39	610048-00	OTR CLMP WASHER	1
40	605097-00	BLADE BOLT	1
41	330003-64	BALL BEARING	1
44	N415907	ARMATURE & BEARING	1
45	N234639	MAGNET RING	1
46	N412223	BRUSH HOLDER ASSY	1
48	N333139	BAFFLE	1
50	N389143	THREAD FORMING SCREW	2
51	605082-00SV	GEARCASE ASSY	1
52	330045-45	SCREW	4
800	761995-01	GREASE, 6 OZ.	1
800	283484-01	GREASE,32 OZ.	1
856	628425-01	BLADE	1
856	381091-00	GUIDE,EDGE	1
861	N153976	KITBOX	1
862	605265-00	SPRING CLIP	1
866	DCB200	BATTERY PACK	1

### Parts List for DCS393 Type 3

Item Number	Part Number	Description	Qty Required
871	DCB101	CHARGER	1