








**TORQUE SPECS\***



Item	Ft/Lb	Nm
2	14.7	20
10	73.7	100
12	7.3	10
26	7.3	10
28	14.7	20
35	11.0	15
64	7.3	10

\*Decrease torque by 20% if threads are lubricated.









## Parts List for DP3400HR Type 1

Item Number	Part Number	Description	Qty Required
1	A16004	PUMP ASSEMBLY	1
2	A08896	SCREW	8
3	P313	WASHER LOCK GEN 9670	8
9	A08904	ORING	6
10	A08905	CAP VALVE	6
11	A08927	KIT VALVE	1
12	15713	SCREW .250-20X.50 GE	8
13	15898	COVER BEARING	1
14	A08906	INDICATOR OIL LEVEL	1
15	15727	ORING	2
17	A08928	KIT OIL SEAL	1
19	P467	DIPSTICK	1
22	A08907	GUIDE PLUNGER	3
23	A08908	ROD CONNECTING	3
24	A08909	ORING COVER	1
25	A08910	COVER REAR CRANKCASE	1
26	A08911	SCREW	1
27	A08912	ORING	1
28	A08913	PLUG	2
29	A08914	PIN CON ROD	3
30	A08915	FLINGER WASHER	3
31	A08916	RING ANTI EXTRUSION	3
32	A08917	ORING	3
33	P619	PLUNGER CERAMIC GEN	3
34	A08918	BUSHING	3
35	15838	NUT PLUNGER GEN 9222	3
40	A08930	RETAINER	3

## Parts List for DP3400HR Type 1

Item Number	Part Number	Description	Qty Required
41	A08929	KIT WATER PACK	1
42	5140058-69	O-RING	3
43	A08931	RETAINER	1
49	A08919	INDICATOR OIL LEVEL	1
50	A08920	ORING	1
61	A08921	FLANGE ENGINE	1
62	5140046-41	OIL SEAL	1
63	A08922	WASHER	4
64	A08922	WASHER	4
91	A08934	KIT UNLOADER	1
120	P064	ORING GEN 90383200	1
121	A08924	NIPPLE	1
130	A08925	ORING	1
131	A08926	NOZZLE	1
132	A08935	INJECTOR CHEMICAL	1
201	A15668	ENGINE	1
202	D23124	LABEL,WARNING	1
203	A14552	LABEL HOT SURFACE	1
205	A16004	PUMP ASSEMBLY	1
206	A16412	LABEL WARNING	1
208	A11349	BOLT .375-16X1.25 FL	4
209	A13853	FRAME	1
210	000000-00	No Longer Available	1
211	000000-00	No Longer Available	1
212	18300	BOLT .375-16X1.75 FL	4
213	A00253	TIRE PNEU 12 X 4 STU	2
214	D30249	COLLER AXLE SET SCRE	2



## Parts List for DP3400HR Type 1

Item Number	Part Number	Description	Qty Required
215	A16267	LABEL WARNING	1
216	A16268	LABEL WARNING	1
217	A16269	LABEL WARNING	1
218	1000001689	HIGH PRESSURE HOSE	1
218	H140	HOSE ASSY CHEMICAL	1
219	D21436	SCREW .250-20X.750 U	2
220	D21437	NUT.250-20 FLANGEHEA	2
221	D22268	ISOLATOR RECESSED RU	2
222	NCT001	TOOL NOZZLE CLEANING	1
223	D30374	NOZZLE HOLDER RUBBER	1
224	17731	NOZZLE KIT 4.0 5 PAC	1
225	5140095-05	GUN	1
225	F179	ORING 1/4 QC	1
226	N000579	HOSE ASSEMBLY	1
227	1000000390	LANCE	1
227	F179	ORING 1/4 QC	1
228	A19985	SOCKET QUIK CONNECT	1
229	D30492	BUTTON SNAP .302 DIA	1
230	A17354	NAMEPLATE	1
231	17086	REEL HOSE 100 CAP 3/	1
232	A16255	HANDLE	1
233	16087	NUT .313-18 UNC FLAN	4
234	F064	SCREW .313-18X1.00 H	4
237	F038	PLUG MALE 3/8	1
238	F039	PLUG QUICK CONNECT F	1
239	17657	VALVE THERMAL RELIEF	1
257	16829	ADAPTER 1/2	1

## Parts List for DP3400HR Type 1

Item Number	Part Number	Description	Qty Required
401	285805-44	GASKET	1
402	285805-45	ELEMENT	1
403	285805-46	FILTER	1
404	285805-47	COVER	1
405	285800-05	GROMMET	1
406	285805-48	COLLAR	2
407	285800-07	COLLAR	1
408	285805-49	ELBOW	1
409	285800-46	NUT	2
411	285800-11	WING NUT	2
413	285805-50	BOLT	1
419	285804-83	FAN	1
420	285805-84	FLYWHEEL	1
421	285803-05	NUT	1
422	285803-06	KEY	1
423	285804-84	PULLEY	1
425	285807-52	CRANKSHAFT	1
426	285807-53	BALL BEARING	1
427	285804-46	CAMSHAFT	1
428	285804-47	PUSH ROD	2
429	285803-12	ARM	2
430	285803-13	LIFTER	2
431	285800-18	PIVOT	2
432	285800-19	SPRING	1
433	285804-48	VALVE	1
434	285804-49	VALVE	1
435	285803-16	SPRING	2

## Parts List for DP3400HR Type 1

Item Number	Part Number	Description	Qty Required
436	285803-17	RETAINER	1
437	285803-18	RETAINER	1
438	285803-19	SEAT	1
439	285803-20	ROTATOR VALVE	1
440	285803-21	PLATE	1
441	285800-27	BOLT	2
442	285800-28	NUT	2
443	285803-22	SEAL	1
447	285805-51	GASKET SET	1
448	285803-76	VALVE SET	1
449	285803-77	FLOAT SET	1
450	285805-61	CHAMBER SET	1
451	285800-51	SET SCREW	1
452	285800-52	SET SCREW	1
453	285800-53	SET SCREW	1
454	285805-52	CHOKE SET	1
455	285807-54	CARBURETOR	1
456	285800-56	SCREW	1
457	285807-55	NOZZLE	1
458	285800-58	O-RING	1
459	285805-55	INSULATOR	1
460	285804-54	GASKET	1
461	285805-56	SPACER	1
462	285804-53	GASKET	1
463	285800-63	LEVER	1
464	285800-64	LEVER	1
465	285800-65	PLATE	1

## Parts List for DP3400HR Type 1

Item Number	Part Number	Description	Qty Required
466	285800-66	SPRING	1
467	285800-67	GASKET	1
468	285800-68	CUP	1
469	285800-69	SCREW	1
470	285800-70	PIN	1
471	285805-58	MAIN JET	1
471	285805-57	MAIN JET	1
471	285804-57	JET	1
472	285805-60	JET	1
474	285801-10	O-RING	1
475	285801-11	NUT	1
476	285802-82	WASHER	2
477	285802-83	LOCK PIN	1
478	285801-14	BOLT	2
480	285801-22	OIL ALERT UNIT	1
481	285800-41	BOLT	1
482	285804-75	CYLINDER HEAD	1
483	285802-86	GUIDE	1
484	285802-87	GUIDE	1
485	285802-88	CLIP	1
486	285807-56	GASKET	1
487	285802-90	COVER	1
488	285802-91	GASKET	1
489	285802-92	BOLT	1
490	285805-79	BOLT	2
491	285802-94	BULK HOSE	1
492	285802-95	BOLT	2

## Parts List for DP3400HR Type 1

Item Number	Part Number	Description	Qty Required
493	285802-96	WASHER	1
494	285802-97	PIN	2
495	285804-79	BOLT	4
496	285804-80	SPARK PLUG	1
497	285805-07	STARTER ASSY.	1
498	285805-08	CASE	1
499	285805-09	PULLEY	1
500	285803-42	RATCHET	2
501	285803-43	SPRING	1
502	285803-44	SPRING	1
503	285804-38	BOLT	2
504	285803-46	RETAINER	1
505	285803-45	SPRING	1
506	285803-48	GRIP	1
507	285805-10	ROPE	1
508	285804-74	SEAL	1
510	285803-50	SCREW	1
511	285802-79	WASHER	1
533	285801-33	RUBBER TUBE	1
534	285801-34	JOINT	1
535	285805-85	TANK	1
536	285807-03	FUEL CAP	1
537	285807-04	GASKET	1
538	285801-10	O-RING	1
539	285803-72	NUT	2
540	285801-40	HOSE	1
541	285801-41	CLIP	2

## Parts List for DP3400HR Type 1

Item Number	Part Number	Description	Qty Required
542	285805-87	BOLT	2
543	285801-53	BOLT	3
547	285803-84	COLLAR	1
567	285805-89	MUFFLER	1
568	285805-90	PROTECTOR	1
569	285805-91	PROTECTOR	1
570	285805-92	EXHAUST PIPE	1
572	285803-68	GASKET	1
573	285805-94	SPARK ARRESTOR	1
574	285805-95	GASKET	1
575	285800-41	BOLT	1
576	285801-71	SCREW	6
577	285801-72	SCREW	1
578	285803-72	NUT	5
579	285807-67	LABEL	1
580	285807-57	GASKET	1
583	285804-86	IGNITION COIL	1
584	285801-30	CAPACITOR ASSY	1
588	285804-24	GROMMET	1
589	285801-31	WIRE	1
593	285802-29	BOLT	2
594	285807-58	EMBLEM	1
599	285805-86	FILTER	1
602	285807-59	COVER ASSY	1
603	285804-64	GASKET	1
604	285800-77	CAP ASSY.	1
605	285802-74	CAP ASSY.	1

## Parts List for DP3400HR Type 1

Item Number	Part Number	Description	Qty Required
606	285800-78	GASKET	2
607	285805-72	GOVERNOR ASSY.	1
608	285804-67	WEIGHT	2
609	285805-73	HOLDER	1
610	285802-67	PIN	1
611	285802-68	SLIDER	1
612	285801-07	CLIP	1
613	285802-73	DOWEL PIN	2
614	285804-74	SEAL	1
615	285801-12	WASHER	1
616	285804-70	BOLT	1
618	285804-71	BALL BEARING	1
620	285805-77	KEY	1
626	285805-80	CLIP	1
629	285805-64	CONTROL ASSY	1
630	285805-62	ARM	1
631	285804-60	ROD	1
632	285804-61	SPRING	1
633	285805-63	SPRING	1
634	285805-65	LEVER	1
635	285800-35	SPRING	1
636	285805-66	WASHER	1
637	285800-37	HOLDER	1
638	285805-67	SPACER	1
639	285800-39	SPRING	1
640	285805-69	SPRING	1
641	285800-41	BOLT	2

## Parts List for DP3400HR Type 1

Item Number	Part Number	Description	Qty Required
642	285800-42	BOLT	1
643	285800-43	NUT	1
644	285805-70	SCREW	1
645	285802-21	SCREW	1
646	285800-46	NUT	1
654	285807-62	RING SET	1
654	285807-61	RING SET	1
654	285807-60	RING SET	1
655	285807-65	PISTON	1
655	285807-64	PISTON	1
655	285807-63	PISTON	1
656	285805-04	PIN	1
657	285805-06	ROD	1
657	285805-05	ROD	1
658	285803-37	BOLT	2
659	285801-66	CLIP	2
660	285805-81	COVER	1
661	285804-82	SHROUD	1
662	285806-99	SWITCH ASSY.	1
663	285800-41	BOLT	6
664	285805-82	CLIP	1
665	285807-66	CYLINDER	1
666	285802-76	SWITCH ASSY	1
667	285804-73	SHAFT	1
675	285807-69	LABEL	1
676	285807-68	LABEL	1
700	285807-70	WRENCH	1