



Parts List for DR601K Type 1

Item Number	Part Number	Description	Qty Required
1	611720-01	HOUSING & COVER	1
2	607882-00	OUTPUT SPND.ASY	1
4	618336-00	WASHER	1
6	87348-00	CHUCK & KEY	1
7	607883-00	REAR BRG PLATE	1
8	607924-00	GEAR,INTER.	1
9	385992-02	ARMATURE ASSY.	1
10	607888-00	RETAINING RING	1
11	148902-00	WASHER,PLAIN	1
12	158478-00	SINK,HEAT	1
13	037381-00	WASHER	1
14	385848-01	FIELD	1
15	385995-01	REVERSE RING	1
16	611278-00	REVERSE LEVER	1
17	611719-01	VS SWITCH	1
18	330073-98	CORD/8 FT/18-2	1
19	000000-00	No Longer Available	1
20	380414-00	CLAMP,CORD	1
21	330019-03	SCREW	8
22	330019-08	SCREW	2
23	617990-00	NAME PLATE	1
25	385733-01	BRUSH	2
26	607881-00	GEARCASE/BRGS	1
27	607888-00	RETAINING RING	1
28	618319-00	GEAR & BEARING	1
29	605256-01	SCREW	1
30	330019-15	SCREW	4

Parts List for DR601K Type 1

Item Number	Part Number	Description	Qty Required
31	618324-00	SPRING	1
32	611279-00	KNOB	1
40	621400-00	CHUCK KEY	1
40	330034-06	CHUCK KEY	1
41	614670-00	SIDE HANDLE	1
42	000000-00	No Longer Available	1
43	000000-00	No Longer Available	1
44	000000-00	No Longer Available	1
46	607868-00	COMP. SPRING	1
47	607875-00	THRUST WASHER	1
50	000000-00	No Longer Available	1
51	372814-00	DEPTH STOP	1
800	429698-00	GREASE:4 LB CAN	1
861	000000-00	No Longer Available	1