



Parts List for DR670 Type 1

Item Number	Part Number	Description	Qty Required
4	90547778	BRUSH	2
6	629530-01	KEYLESS CHUCK	1
20	90512961	SCREW,TERMINAL	1
28	90547752	SIDE HANDLE ASY	1
29	372814-00	DEPTH STOP	1