



Parts List for DW268-BR Type 5

Item Number	Part Number	Description	Qty Required
1	176853-01SV	ARMATURE & FAN	1
2	620360-04SV	FIELD & LEADS	1
3	176846-04	BRUSH	2
5	390004-00	BR.HOLDER,L	1
6	390003-00	BR.HOLDER,R	1
7	621884-00	SWITCH	1
8	330122-74	CORDSET	1
9	330003-04	BEARING,BALL	1
10	330003-04	BEARING,BALL	1
13	396969-14	FIELD CASE	1
14	176816-06	HANDLE COVER	1
15	176833-00	CLAMP,CORD	1
16	148809-00	PROTECTOR,CORD	1
17	330019-13	SCREW,M4X19	3
18	176951-00	SCREW	2
19	389824-00	CUP	1
20	176811-00	BAFFLE	1
21	949638-02	PLUG,RUBBER	2
22	395047-00	ID LABEL	1
23	N026860	NAMEPLATE	1
24	176709-00SV	CASE-GEAR	1
25	N045425	BELT CLIP	1
26	330003-09	BEARING,BALL	1
27	176708-00SV	SPINDLE & GEAR	1
28	388761-00	GEAR CASE COVER	1
29	023813-00	WASHER	1
30	450556-00	NOSEPIECE	1

Parts List for DW268-BR Type 5

Item Number	Part Number	Description	Qty Required
31	090626-00	SLEEVE BEARING	1
32	021287-00	GUIDE	1
33	090866-00	WASHER	1
34	086134-00	SPRING	1
35	450360-00	SPINDLE	1
36	099047-01	BALL	1
37	090639-02	ADJ.COLLAR	1
38	387451-00	BALL RETAINER	1
39	450555-00	STOP,ADJUST.	1
40	90596-00	SEAL	1
41	087928-00	LOCATOR SPRING	1
42	21360-00	RING	1
43	616118-02	LEADWIRE ASSY.	1
44	616118-03	LEADWIRE ASSY.	1
45	330019-14	SCREW	1
46	176655-00	GASKET	1
47	000903-00	BALL	8
48	087692-00	RET RING	1
49	093105-01	CLUTCH HOUSING	1
50	093128-00	NEEDLE BEARING	2
52	86211-00	SPRING	1
54	330004-00	BEARING,NEEDLE	1
55	176731-00SV	SPINDLE & GEAR	1
56	176732-00	WASHER,THRUST	3
57	143079-00	WASHER,THRUST	1
58	330019-16	SCREW	2
59	089210-00	RET RING	2

Parts List for DW268-BR Type 5

Item Number	Part Number	Description	Qty Required
60	400970-01	CLUTCH	2
61	330019-04	SCREW,PLASTITE	2
800	761995-01	GREASE, 6 OZ.	1
800	283484-01	GREASE,32 OZ.	1
800	284778-00	GREASE,MOLYKOTE	1