







Parts List for DW616PK Type 1

Item Number	Part Number	Description	Qty Required
1	396310-01	MOTOR HOUSING	1
2	146555-01	BEARING, BALL	1
3	394219-00	CLAMP NUT	1
4	398221-00SV	ARMATURE & BRG.	1
5	330045-57	SCREW	3
6	399064-00	TOGGLE SWITCH	1
7	399028-00	SWITCH BOOT	1
8	397500-00	RECEPTACLE	1
9	397501-00	WIRE GUARD	1
10	397564-00	END CAP	1
11	33055-00	PLUG	1
12	330045-09	SCREW	4
13	150036-00	SCREW,GROUND	1
14	399063-00	CORDSET	1
15	330003-09	BEARING,BALL	1
16	053650-03	TERMINAL	1
17	608552-00	GROUND WIRE	1
18	608551-00	LEADWIRE	1
19	397566-01	BRUSH RING ASM	1
20	398139-01	BRUSH ASSY.	2
21	397569-00SV	FIELD	1
22	330019-27	SCREW,TORX	2
23	398216-00	FIELD CASE	1
24	5140060-14	COLLET & NUT	1
24	326286-04	COLLET & NUT	1
24	326286-03	COLLET & NUT	1
25	399068-00	WRENCH	2

Parts List for DW616PK Type 1

Item Number	Part Number	Description	Qty Required
26	612616-00	NAME PLATE	1
34	607523-00	SUB BASE ALIGN. CONE	1
35	607522-00	BASE ALIGN. SHAFT	1
100	396308-00	FIXED BASE	1
101	330041-45	ROLL PIN	3
102	397560-00	KNOB	2
103	607395-00	SCREW	2
104	098197-09	LOCKWASHER	2
105	397531-01	SUB BASE	1
105	397531-00	SUB BASE	1
106	609842-00	SCREW	4
107	397503-00	CLAMP LEVER	1
108	397504-00	THREADED ROD	1
109	330021-01	NUT,STOP	1
110	606623-00	SPACER	1
111	397406-00	LATCH RELEASE	2
112	397411-00	SPRING	2
113	330041-44	ROLLER PIN	2
114	397450-00	ID LABEL	1
115	397451-00	LABEL	1
116	396311-00	ADJUSTING RING	1
117	612054-00	ADJUSTING RING	1
200	398086-00S	BASE ASSEMBLY	1
201	326976-01	TURRET	1
202	608928-00	SCREW,M5 X 20	1
203	330015-04	NUT,HEX	1
204	398052-00	CARRIER ASSY.	1

Parts List for DW616PK Type 1

Item Number	Part Number	Description	Qty Required
205	397503-00	CLAMP LEVER	1
206	397504-00	THREADED ROD	1
207	330041-45	ROLL PIN	1
208	330021-01	NUT,STOP	1
209	606623-00	SPACER	1
210	608920-00	SPRING	1
211	608919-00	SPRING	1
212	608925-00	RETAINING CLIP	1
213	608926-00	RETAINING CLIP	1
214	608924-00	LOCK LEVER	1
215	608933-00	SPRING TORSION	1
216	608929-00	LOCK BOLT	1
217	324007-10	SCREW	1
218	608298-00	STAR WASHER	1
219	608931-00	GUIDE BUSHING	1
220	330045-45	SCREW	2
221	608975-00	COMPR. SPRING	1
222	608932-00	SLEEVE	1
223	397950-00	CARRIER COVER	1
224	330045-45	SCREW	4
225	608921-00	BELLOWS	1
226	608922-00	CAP	1
227	608589-00	DEPTH ROD	1
228	608978-00	ZERO ADJUSTMENT	1
229	396635-01	THUMB SCREW	1
230	609118-00	COMPR. SPRING	2
231	608930-00	SCREW	1

Parts List for DW616PK Type 1

Item Number	Part Number	Description	Qty Required
232	397560-00	KNOB	2
233	607395-00	SCREW	2
234	098197-09	LOCKWASHER	2
235	606275-00	DUST SHROUD	1
236	606246-00	SUB BASE	1
237	609842-00	SCREW	3
238	397448-00	DEPTH SCALE	1
239	397449-00	IDENT LABEL	1
240	606907-00	LABEL	1
241	608805-00	VACUUM ADAPTER	1
242	326467-00	DETENT	1
243	391352-00	SPRING WASHER	1
244	330045-57	SCREW	1
245	608972-00	SPRING,EXT.	1
250	330045-07	SCREW M4X20 T20	1
251	653599-00	WASHER	1
252	652835-00	SPACER	1
253	652834-00	SPRING	1
254	652836-00	BALL	1
861	397684-00	KIT BOX	1
876	397591-00	MOTOR ASSEMBLY	1