



Parts List for DW818 Type 5

Item Number	Part Number	Description	Qty Required
101	401702-11	ARMATURE	1
102	605527-01	FIELD & LEADS	1
103	945614-00	SWITCH,ON/OFF	1
104	939539-00	BRUSH,CUTOFF	2
105	330072-47	POWER CORD	1
106	611672-00	OUTER FLANGE	1
107	397616-00	FLANGE	1
110	397661-01	GUARD	1
111	631609-02	SCREW	1
112	330045-46	SCREW	4
114	604488-10SV	SPINDLE ASSY	1
116	330005-01	PROTECTOR,CORD	1
118	562097-01	SCREW	4
119	615073-00SV	GEAR CASE ASSY.	1
121	562211-00	HANDLE,SIDE	1
123	945292-00	NUT	1
124	944575-00	BUTTON,LOCK	1
125	562210-00	SPRING	1
126	944571-00	LOCK,SPINDLE	1
128	641823-00	BEARING CUP	1
129	401623-00	BAFFLE	1
130	949638-01	PLUG,RUBBER	2
132	606574-01SV	BRUSH HOLDER	2
133	562204-00	SPRING	2
134	615071-03S	FIELD CASE ASSY	1
135	605040-02	BALL BEARING	1
136	613186-00	END CAP	1

Parts List for DW818 Type 5

Item Number	Part Number	Description	Qty Required
137	611540-00	SWITCH SUPPORT	1
138	401680-00	WRENCH	1
139	562097-05	SCREW	1
140	401622-01	RETAINER,BRG	1
145	562097-00	SCREW	2
153	562100-01	PINION	1
160	330003-60	BEARING	1
162	611737-01	SWITCH LINK	1
163	569624-01	SWITCH BUTTON	1
164	562097-13	SCREW	1
166	398906-00	SLINGER	1
171	393799-00	O-RING	1
172	393802-00	LABEL	1
800	286436-00	GREASE	1
821	615105-00	NAME PLATE	1
856	643772-00	GUARD	1
856	DW4514	4-1/2X1/4 METL	1