



## Parts List for DW861B-AR Type 2

| Item Number | Part Number | Description         | Qty Required |
|-------------|-------------|---------------------|--------------|
| 1           | 647896-00   | ARMATURE ASSY.      | 1            |
| 2           | 000000-00   | No Longer Available | 1            |
| 3           | 185440-01   | FIELD               | 1            |
| 4           | 561914-02   | SCREW               | 2            |
| 5           | 561914-01   | SCREW               | 3            |
| 6           | 562228-00   | GEAR CASE           | 1            |
| 7           | 562229-00   | SPINDLE & GEAR      | 1            |
| 8           | 561917-02   | O RING              | 1            |
| 9           | 562252-00   | GEAR CASE COVER     | 1            |
| 10          | 561917-01   | O RING              | 1            |
| 11          | 561914-00   | SCREW               | 3            |
| 12          | 562231-00   | INNER FLANGE        | 1            |
| 13          | 562232-00   | OUTER FLANGE        | 1            |
| 14          | 185335-00   | SCREW               | 1            |
| 15          | 562215-00   | BAFFLE              | 1            |
| 16          | 000000-00   | No Longer Available | 1            |
| 17          | 562097-03   | SCREW               | 4            |
| 18          | 562221-00   | HANDLE COVER        | 1            |
| 19          | 561913-00   | LEAD                | 2            |
| 20          | 330005-01   | PROTECTOR,CORD      | 1            |
| 21          | 562097-00   | SCREW               | 2            |
| 22          | 000000-00   | No Longer Available | 1            |
| 23          | 185251-00   | SWITCH              | 1            |
| 24          | 562224-00   | SWITCH BOOT         | 1            |
| 25          | 000000-00   | No Longer Available | 1            |
| 26          | 562227-00   | BRUSH HOLDER        | 2            |
| 27          | 562218-00   | BRUSH HOUSING       | 2            |

## Parts List for DW861B-AR Type 2

| Item Number | Part Number | Description         | Qty Required |
|-------------|-------------|---------------------|--------------|
| 28          | 562217-01   | BRUSH               | 2            |
| 29          | 562219-00   | BRUSH CAP           | 2            |
| 30          | 000000-00   | No Longer Available | 2            |
| 31          | 562222-00   | END CAP             | 1            |
| 32          | 562097-05   | SCREW               | 2            |
| 33          | 185108-01   | CORD                | 1            |
| 34          | 561920-00   | STOPPER PIN         | 1            |
| 35          | 562210-00   | SPRING              | 1            |
| 36          | 561918-00   | LEVER               | 1            |
| 37          | 562235-00   | BOLT                | 1            |
| 38          | 561916-00   | WASHER              | 1            |
| 39          | 561934-02   | SHOE                | 1            |
| 40          | 562369-00   | SQUARE BOLT         | 1            |
| 41          | 569657-00   | HEX BOLT            | 1            |
| 42          | 403148-00   | WASHER              | 2            |
| 43          | 562368-00   | WING NUT            | 2            |
| 44          | 185244-00   | SPRING WASHER       | 3            |
| 45          | 330015-02   | NUT,HEX             | 1            |
| 46          | 562239-00   | WET ACCESSORIES     | 1            |
| 47          | 098000-11   | WRENCH              | 1            |
| 48          | 389848-00   | WRENCH              | 1            |
| 49          | 569723-00   | DEFLECTOR           | 1            |
| 50          | 949721-05   | BEARING CUP         | 1            |
| 51          | 562230-00   | ID LABEL            | 1            |
| 52          | 000000-00   | No Longer Available | 1            |
| 53          | 000000-00   | No Longer Available | 1            |
| 54          | 330003-03   | BEARING,BALL        | 1            |

## Parts List for DW861B-AR Type 2

| Item Number | Part Number | Description  | Qty Required |
|-------------|-------------|--------------|--------------|
| 55          | 605040-42   | BALL BEARING | 1            |
| 60          | 562249-00   | GEAR         | 1            |
| 61          | 330003-47   | BEARING,BALL | 1            |
| 62          | 562250-00   | OUTPUT SHAFT | 1            |