



Parts List for DW896 Type 3

Item Number	Part Number	Description	Qty Required
1	619548-00SV	ARMATURE	1
2	619549-00	FIELD	1
3	445861-25	BRUSH	2
4	445860-00	SPRING,BRUSH	2
5	449899-05	RING,BRUSH	1
7	625238-00	SWITCH	1
7	625238-00	SWITCH	1
7	625238-00	SWITCH	1
8	330072-98	CORD/8FT/18-2SJ	1
9	330003-04	BEARING,BALL	1
10	330003-04	BEARING,BALL	1
11	330019-14	SCREW	4
12	869219-04	GEAR & PINION	1
13	448269-00	SCREW	2
14	931892-00	WASHER	1
15	930102-00	WASHER	1
16	935845-00	GEAR,ECCENTRIC	1
17	330019-13	SCREW,M4X19	4
18	935861-00	SPACER	1
19	445217-01	RUBBER CUP	1
21	935860-00	BEARING,ROLLER	2
22	935864-00	CAP	1
24	932839-00	WASHER	3
25	397659-00	LOCK BUTTON	1
26	397655-00SV	PADDLE ASSY.	1
27	445876-00	BAFFLE, FAN	1
28	N107382	END CAP	1

Parts List for DW896 Type 3

Item Number	Part Number	Description	Qty Required
29	935855-00	PIN	1
30	935371-00	SCREW	3
31	935858-00	SHAFT	1
32	935848-00	BEARING,ROLLER	1
33	935849-00	ROD,CONNECTING	1
34	935847-00	RING,RETAINING	1
35	935863-00	RING, O	1
36	330005-01	PROTECTOR,CORD	1
37	936931-00	WASHER,SPRING	1
38	445886-06SV	CASE-FIELD	1
40	445882-00	CONTACT STRIP	2
41	935859-00	PUNCH	1
42	935851-00	DIE	1
43	935884-00	LABEL	1
44	935854-00	BEARING,SLEEVE	1
45	935856-00	NUT,LOCK	1
47	652122-00	WARNING LABEL	1
48	935852-00	COLLAR	1
49	936095-00	COVER,GEAR CASE	1
51	935838-00	CASE,GEAR	1
52	945857-00	SCREW	1
53	449923-00	FLYWHEEL	1
54	935842-00	PIN	1
55	935857-00	RING, O	1
56	868970-00	GASKET	1
57	869391-00	WASHER	2
58	464228-00	TERMINAL	2

Parts List for DW896 Type 3

Item Number	Part Number	Description	Qty Required
59	N142238	NAME PLATE	1
60	447193-00	WRENCH	1
61	99056-02	WRENCH,HEX	1
62	330004-02	BEARING,NEEDLE	1
63	930302-00	BEARING, ROLLER	1
64	395047-00	ID LABEL	1
66	932309-00	WASHER	1
67	87891-05	TUBING,HT.SHRNK	1
68	N115041	LEAD ASSY.	2
800	761995-01	GREASE, 6 OZ.	1
800	283484-01	GREASE,32 OZ.	1
806	447465-00	OIL,BOTTLE	1