



Parts List for DW997K-B2 Type 3

Item Number	Part Number	Description	Qty Required
1	392654-06	CLAMSHELL SET	1
2	798954-00	WASHER,RETAIN.	1
3	151936-02	GEAR,PLANET 1ST	5
4	385408-00SV	CARRIER	1
5	393111-01	MOTOR & PINION	1
7	152274-19SV	SWITCH- V.S.R.	1
8	391114-00	BUTTON(FWD/REV)	1
8	151296-00	BUTTON,REV.	1
9	153281-03	SHIFTER	1
10	144658-00	SPRING	1
11	799013-01	COLLAR,ADJUST	1
12	330075-59	KEYLESS CHUCK	1
13	605256-01	SCREW	1
14	148354-03	BIT CLIP	2
15	607918-41	SCREWDRIVER BIT	1
16	330019-00	SCREW	5
17	98091-11	SCREW	6
18	330019-04	SCREW,PLASTITE	7
19	608550-00	PLANET GEAR	5
22	395657-00	ID LABEL	1
23	DE9095	18V XR2 BATTERY PACK	1
24	000000-00	No Longer Available	1
25	805068-01	GEAR,RING 2-RED	1
26	372274-00	GEAR,PLANET 2ND	5
27	798701-00	CASE,GEAR	1
28	389025-00SV	BRUSH PAIR KIT	1
29	389025-00SV	BRUSH PAIR KIT	1

Parts List for DW997K-B2 Type 3

Item Number	Part Number	Description	Qty Required
30	152482-00	SEAL,FOAM	1
31	000000-00	No Longer Available	1
32	392755-00	GEAR,OUTPUT	1
33	805063-02	GEAR,RING	1
34	000000-00	No Longer Available	1
35	798966-01	HOUSING ASSY	1
36	805004-00	WASHER,FLANGE	1
37	798959-00	CLIP,BEARING	1
38	380792-00	PLATE,DETENT	1
39	380793-00	PIN	6
40	798709-00	NUT,ADJUSTING	1
41	385490-00	SPINDLE,OUTPUT	1
42	386690-00	BALL	6
43	152347-00	SPRING	6
44	395300-00	RETURN SPRING	1
45	384917-00	RING,CAM	1
46	798689-00	PLATE,THRUST	1
47	799981-00	SPRING,HAMMER	1
49	000000-00	No Longer Available	1
50	380264-13SV	TRANSMISSION	1
51	385475-00	CLUTCH	1
800	284778-00	GREASE,MOLYKOTE	1
861	660141-00	KITBOX	1