





Parts List for DWS780-B2 Type 1

Item Number	Part Number	Description	Qty Required
1	N240379	ARM ASSEMBLY	1
2	618193-00	BELT COVER	1
3	330045-14	SCREW,M5 X 16MM	5
4	146751-00	SHAFT,PIVOT	1
5	146732-00	SPACER	2
6	N039404	TORSION SPRING	1
7	150075-00	SCREW,SET	2
8	148296-00	WASHER,SPRING	2
9	387130-00	LOCKING PIN	1
10	034158-00	O RING	1
11	N058304	REAR GUARD	1
12	330045-23	SCREW,TAPTITE	8
13	153603-01	PAWL	1
14	153639-00	SCREW,SHOULDER	5
15	153655-00	WASHER,WAVY	2
16	618197-00	SCREW	1
17	150718-00	NUT,WING	1
18	N030317	WORK LIGHT	1
20	618198-00	SCREW	1
23	145344-01	BOLT	1
24	151962-01	CLAMP,OUTER	1
25	152636-00	ADAPTOR,BLADE	1
26	644999-00	BUSHING,ARBOR	1
28	393702-00SV	SPINDLE & GEAR	1
29	330003-66	BEARING, BALL	1
30	391616-00	NEEDLE BEARING	1
31	393703-00SV	GEAR-INTER.	1

Parts List for DWS780-B2 Type 1

Item Number	Part Number	Description	Qty Required
32	330003-09	BEARING,BALL	1
33	605040-33	BEARING	1
34	N027131SV	PINION SHAFT	1
35	153752-00	RING,RET.EXT	2
36	618244-00	RETAINING PLATE	1
37	330045-49	SCREW	12
38	391310-00	BEARING PLATE	1
39	330045-49	SCREW	3
40	N004511	DRIVEN PULLEY	1
44	393935-00SV	GR CASE CVR ASY	1
45	391315-00	GASKET	1
47	153555-00	BELT	1
48	N004510	DRIVE PULLEY	1
49	153561-00	PIN,LOCK	1
50	448176-00	SPRING	1
51	393071-00	RET. PLATE	1
52	330045-45	SCREW	8
53	153559-00	WASHER,FELT	1
56	146740-00	SLEEVE,FLANGED	2
57	394589-01	SCREW	2
60	330045-15	SCREW,M5X20	5
61	N041726	DUST DUCT ASSY.	1
62	N080677	LOCK KNOB	1
68	N058308	BEVEL POINTER	1
69	N058309	BEVEL POINTER	1
70	N080199	KNOB	1
72	060325-01	RING	1

Parts List for DWS780-B2 Type 1

Item Number	Part Number	Description	Qty Required
74	330045-06	SCREW	7
76	N090294	BEVEL SCALE	1
80	N043045	PAWL	2
83	N049689	STOP PLATE	1
85	N051519	STOP PLATE	1
91	330015-03	NUT,HEX	1
92	N058312	SCREW	2
93	N088862SV	BASE ASSY.	1
94	618192-00	WEAR PLATE	1
95	N057391	KERF PLATE	1
96	N240439	TABLE ASSEMBLY	1
97	618172-00	COVER	1
99	049787-00	O RING	1
100	N058318	SCREW	1
101	N044739	LOCK NUT	1
102	153792-00	WASHER	3
103	N059784	DETENT PLATE	1
104	604410-00	SCREW	2
105	391358-01	WRENCH HOLDER	1
106	608563-01	WRENCH	1
107	N057963	POINTER	1
108	N050755	ACTUATOR	1
109	N066280	CLAMP PLATE	2
110	622396-00	SHAFT	1
111	622395-00	LEVER	1
112	624477-00	DETENT	1
113	618176-00	SPRING	1

Parts List for DWS780-B2 Type 1

Item Number	Part Number	Description	Qty Required
114	093128-00	NEEDLE BEARING	2
115	618254-00	RETAINER	1
116	N082785	LEVER	1
117	N057386	PIN	1
118	624460-00	PIVOT PIN	1
119	624461-00	SLEEVE	1
120	618186-00	ROD	1
121	618185-00	BLOCK	1
122	385915-03	SHOULDER SCREW	1
123	618253-00	SPRING	1
124	624730-00	HANDLE SET	1
125	330045-18	SCREW	4
126	330019-32	SCREW	5
127	N078832	POWER SUPPLY	1
128	606056-00	SWITCH	1
129	384127-01	SCREW	4
130	330045-25	SCREW,TAPTITE	1
131	N114499	MOTOR CORD	1
132	N104993	CORD	1
133	N083060	HANDLE	1
134	330019-22	SCREW	1
135	398443-00	CABLE CLAMP	1
137	N030322	COVER	1
138	N032306	FENCE	1
139	N240440	LEFT FENCE	1
140	N082686	RIGHT FENCE	1
141	147107-02	KNOB	2

Parts List for DWS780-B2 Type 1

Item Number	Part Number	Description	Qty Required
142	098105-03	SCREW	4
143	391317-05	FIELD CASE	1
144	N030189SV	ARMATURE ASSEMBLY	1
145	391318-01SV	FIELD	1
146	391282-00	MOTOR MOUNT	1
147	394034-00	SET SCREW	1
148	N127530	BALL BEARING	1
149	330003-60	BEARING	1
150	144803-00	RING,RET.	1
151	145312-00	PLUG,RUBBER	1
152	98094-55	SCREW,M5 X 55MM	4
153	391933-01	END CAP	1
154	330019-13	SCREW,M4X19	4
155	330019-19	SCREW	2
156	391375-00	FAN BAFFLE	1
157	389512-01	BRUSH RING ASM	1
158	391325-00	IDENT. LABEL	1
159	N084743	NAMEPLATE	1
160	153783-00	RING,RET.SPIRAL	1
161	605155-00	BUSHING	1
163	330019-12	SCREW	2
170	N084698SV	SUPPORT HOUSING	1
171	603390-00	SCREW	8
172	397118-00	GUIDE	2
173	153576-04	SET SCREW	1
174	613497-00	SLUG	1
176	682149-00	BUSHING,STR.RLF	1

Parts List for DWS780-B2 Type 1

Item Number	Part Number	Description	Qty Required
177	N051244	BUMPER	1
178	659919-00	SPRING,CONICAL	1
179	612008-00	SCREW	1
180	N056883	BEVEL HANDLE	1
181	330016-04	WASHER	1
183	N095579	STOP LEVER	1
184	167785-00	SPRING	1
185	N041865	STOP PIN	1
186	660786-00	BUSHING	1
187	153797-00	SCREW	1
188	N058315	SHOULDER SCREW	2
189	385946-00	WASHER,SPRING	4
192	153797-04	SCREW	2
193	645746-00	BUSHING	2
194	N058306	DUST DEFLECTOR	1
195	153451-00	BEARING,THRUST	1
200	393706-00	LABEL	1
201	630403-00	WARNING LABEL	1
202	148608-00	INSERT	2
203	386780-00	BEARING	2
204	N089041	LOWER GUARD ASSY	1
204	N089043	LOWER GUARD	1
205	N089041	LOWER GUARD ASSY	1
205	N020822	GUARD PLATE	1
206	385915-01	SCREW	4
207	N089041	LOWER GUARD ASSY	1
207	621037-00	PIVOT PLATE	1

Parts List for DWS780-B2 Type 1

Item Number	Part Number	Description	Qty Required
208	146768-00	BUMPER	1
209	618195-00	GUARD LINK	1
212	614843-00	PLATE,RETAINER	1
213	N034013	TORSION SPRING	1
214	148295-00	SLEEVE,PIVOT	1
215	625825-00	ROLLER	2
216	142273-00	RING,RETAINING	2
217	394976-00	LABEL, CAUTION	2
218	146760-02	STUD	1
219	153666-00	SCREW,SET	4
220	630414-00	WARNING LABEL	2
221	145332-00	TERMINAL	4
223	630416-00	WARNING LABEL	2
224	381028-08	BRUSH & LEAD	2
225	395716-00	TERMINAL	4
226	153669-00	CLAMP,CABLE	2
227	385137-00	NUT,STOP	1
228	397117-00	WIPER	4
229	N049684	COVER PLATE	2
230	618142-00	END CAP	1
231	N069475	TRUNNION	1
239	147734-06	BAG,DUST	1
239	DW7053	DUST BAG	1
240	630065-00	CLAMP ASSEMBLY	1
247	N058314	SHOULDER SCREW	2
248	N043046	PAWL	2
250	330019-14	SCREW	1

Parts List for DWS780-B2 Type 1

Item Number	Part Number	Description	Qty Required
800	93488-00	GREASE	1
800	429698-00	GREASE:4 LB CAN	1
856	DW7084	CROWN STOPS	1
856	5140050-83	LENGTH STOP	1
856	DW3126	12IN. 60T SER.20 SAW BLD	1
856	DW7080	EXTENSION SYSTEM	1