



Parts List for DXGN6000 Type PD532MHI004

Item Number	Part Number	Description	Qty Required
1	5140116-83	CARRIER ASSY.	1
2	5140117-00	ENGINE HONDA	1
3	5140115-46	ISOLATOR	5
4	5140115-19	HEX NUT	7
5	5140116-85	BOLT	4
6	5140115-45	LOCK WASHER	4
7	5140115-47	WASHER	2
8	5140115-37	GROUND WIRE	1
9	5140116-40	HEX BOLT	3
10	5140127-13	MUFFLER	1
11	5140116-42	BOLT	2
12	5140118-59	FUEL HOSE	1
13	5140127-15	CAPACITOR	1
13	5140117-01	ALTERNATOR	1
14	5140116-44	BOLT	4
15	5140116-45	BRACKET	1
16	5140116-46	FLAT WASHER	5
17	5140115-77	BOLT	1
18	5140115-41	NUT	1
19	5140117-02	PANEL ASSEMBLY	1
20	5140116-56	SCREW	6
21	5140115-87	VALVE HOLDER	1
22	5140116-91	FUEL TANK ASSY.	1
23	5140116-93	HEAT SHIELD	1
24	5140116-28	SCREW	4
25	5140116-01	CLIP	4
26	5140116-04	SCREW	5

Parts List for DXGN6000 Type PD532MHI004

Item Number	Part Number	Description	Qty Required
27	5140116-08	HOSE CLAMP	1
28	5140116-02	CARBON CANISTER	1
29	5140116-62	CARB CANISTER SHIELD	1
30	5140116-06	FUEL HOSE	1
31	5140115-36	BOLT	4
32	5140116-63	LIFT ASSEMBLY	1
33	5140116-64	LOCK WASHER	2
34	5140116-65	LUG GROUND	1
35	5140116-66	STAR WASHER	1
36	5140116-67	BOLT	1
37	5140116-68	NUT- NYLOCK	2
38	5140116-03	BEZEL	1
39	5140116-69	BOLT	2
40	5140116-70	BRACKET	1
41	5140116-07	GROMMET	1
42	5140116-99	BOLT	1
43	5140115-68	CLAMP	1
44	5140116-00	FLAT WASHER	5
45	5140116-73	HARNESS	1
46	5140116-74	GASKET	1
47	5140115-65	NUT	2
48	5140115-98	VALVE	1
49	5140115-99	BUSHING	1
50	5140116-72	SPARK ARRESTER	1
51	5140116-48	CIRCUIT BREAKER	1
52	5140115-57	CIRCUIT BREAKER	2
53	5140117-03	CIRCUIT BREAKER	1

Parts List for DXGN6000 Type PD532MHI004

Item Number	Part Number	Description	Qty Required
54	5140116-50	SWITCH (ON-OFF)	1
55	5140115-62	ROCKER SWITCH	1
56	5140116-51	HOUR METER	1
57	5140116-52	ROCKER SWITCH	1
58	5140116-53	IDLE CONTROL MODULE	1
59	5140116-54	PANEL CONNECTOR	1
60	5140116-55	STRAIN RELIEF	1
61	5140115-52	RECEPTACLE COVER	2
62	5140115-53	RECEPTACLE COVER	2
63	5140116-92	FUEL FILTER	1
64	5140116-59	CONNECTOR	1
65	5140115-88	FUEL VALVE	1
66	5140118-28	FUEL HOSE	1
66	5140115-95	FUEL HOSE	1
67	5140115-94	HOSE CLAMP	6
68	5140115-55	GROMMET	4
69	5140116-60	FUEL CAP	1
70	5140115-96	FUEL GAUGE	1
71	5140115-48	FUEL FILTER	1
72	5140115-49	INSERT	4
73	5140115-50	FUEL GAUGE DEAL	1
74	5140116-60	FUEL CAP	1
75	5140133-29	RECEPTACLE	2
76	5140127-15	CAPACITOR	1