


7 Exploded View and Replacement Parts List

Model No. : EY7460 Exploded View for EY7460



** Battery Pack is available as an optional accessory. See the nearest sales dealer for details.
 *** For replacement parts of charger, see the charger service manual.
 Charger complete set is available as an optional accessory. See the nearest sales dealer for details.

Model No. : EY7460 Parts List

Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
EY7460					
	1	WEY7460K3078	HOUSING AB SET	1	<SH>
	2	WEY6450L6806	CHUCK FASTENING SCREW	1	<SH>
	3	WEY6450K7915	KEYLESS CHUCK	1	<SH>
	4	WEY7460H3228	CLUTCH HANDLE	1	<SH>
	5	WEY7460H3238	H/L CHANGE HANDLE	1	<SH>
	6	WEY7460H3248	F/R SELECTOR HANDLE	1	<SH>
	7	WEY7460S6028	SEMS SCREW	2	(K3*6) <SH>
	8	WEY7460L1008	DC MOTOR	1	<SH>
	9	WEY7460S6038	SEMS SCREW	2	(K5*6) <SH>
	10	WEY7460K2008	SWITCH	1	<SH>
	11	WEY7460L2118	CONTROL PCB	1	<SH>
	12	WEY7460K3958	OPERATION PANEL	1	<SH>
	13	WEY6405K9218	TORX TAPPING SCREW	9	(K3*20) <SH>
	14	WEY7460L1458	GEAR BOX BLOCK	1	<SH>
	15	WEY7460K4628	SUPPORT HANDLE	1	<SH>
	-	WEY9L40R2788	BATTERY PACK COVER	1	<SH>
	-	WEY7460K7018	TOOL CASE	1	<SH>
	-	WEY7460K8108	OPERATING INSTRUCTIONS	1	<SH>