


7 Exploded View and Replacement Parts List


Please click the radio button for "Diagrams II/Parts List" on the menu bar.

Model No. : EY74A1 Exploded View



* Battery Pack is available as an optional accessory. See the nearest sales dealer for details.

* For replacement parts of charger, see the charger service manual. Charger complete set is available as an optional accessory. See the nearest sales dealer for details.



Model No. : EY74A1 Parts List

Safety	Ref. No.	Part No.	Part Name & Description	Q'ty	Remarks
	1	WEY74A1H3078	HOUSING AB SET	1	
	2	WEY6450L6806	CHUCK FASTENING SCREW	1	
	3	WEY7441K7917	KEYLESS CHUCK	1	
	4	WEY74A1K3228	CLUTCH HANDLE	1	
	5	WEY74A1L4058	DRIVING BLOCK	1	
	6	WEY7460H3237	H/L CHANGE HANDLE	1	
	7	WEY74A1L1008	MOTOR ASSEMBLY	1	
	8	WEY7441L2007	SWITCH ASSEMBLY	1	
	9	WEY7441L6028	SCREW	2	
	10	WEY74A1L2118	MAIN PCB ASSEMBLY	1	
	11	WEY7460K3958	OPERATION PLATE	1	
	12	WEY74A1L0178	CLICK SPRING A	1	
	13	WEY6230K9216	TORX TAPPING SCREW	8	
	14	WEY7547H3247	F/R SELECTOR HANDLE	1	
	15	WEY7441L6487	NUT	1	M4
	16	WEY7441K6217	SCREW	1	4*14
	17	WEY7543K3187	PLATE HOOK	1	
	—	WEY9L40R2788	BATTERY PACK COVER	1	
	—	WEY74A1K7018	TOOL CASE	1	
	—	WEY74A1L8088	OPERATING INSTRUCTIONS	1	