


PORTER-CABLE

ROUND HEAD FRAMING NAILER

WARNING: Repairs should only be attempted by trained repairmen. Contact the nearest Porter-Cable Service Center or other competent repair center.

FR350A



Parts List for FR350A Type 1

Item Number	Part Number	Description	Qty Required
97	N020361	WARNING LABEL	1
98	N020362	NAME PLATE	1
99	903334	LABEL	1
100	904673	WARNING LABEL	1
101	910757	BUSHING-EXHAUST DEFL	1
102	897316	DEFLECTOR	1
103	904269	O-RING (16 X 3)(3016	1
104	886148	GROMMET	1
105	883912	SET SCREW	10
106	897318	BOLT	10
107	A08651	CAP	1
108	910759	WASHER- BEARING (STE	1
109	A03849	PISTON STOP	1
110	910761	SPRING	1
111	A08650	HEAD VALVE PISTON	1
112	910763	QUAD RING (47.04 X3.	1
113	910764	O-RING (61.5 X 3.1)	1
114	910765	GASKET-HOUSING CAP	1
115	897338	SEAT-PRESS RING	1
116	908928	PISTON RING	1
117	60095	DRIVER KIT	1
117	910458	AS/A DRIVER KIT	1
117	911019	DRIVER ASSY	1
118	910767	COLLAR - PU	1
119	910768	CYLINDER	1
120	910769	O-RING (62 X 3.0)	1
121	910770	CYLINDER SPACER	1

Parts List for FR350A Type 1

Item Number	Part Number	Description	Qty Required
122	897389	O-RING	1
123	897387	RING	1
124	897337	BUMPER	1
125	910771	BUMPER SEAT (NYLON)	1
131	911018	DRIVER BLADE (SKD-61	1
200	A08368	SS/A TRIGGER VALVE K	1
201	897340	O-RING	1
202	897341	O-RING	1
203	897342	CAP	1
204	A08369	VALVE PLUNGER	1
205	883936	O-RING	1
206	883938	O-RING	1
207	883939	PLUNGER SPRING	1
208	897346	PLUNGER	1
209	883848	O-RING	1
210	897347	VALVE	1
211	897374	PIN (3X12)	1
212	897349	PIN-SPRING	1
213	897351	PIN	1
214	890725	URETHANE RETAINER	1
215	883884	ROLLED PIN	1
216	908019	SINGLE SEQUENTIAL TR	1
216	906400	SELECTABLE TRIGGER	1
217	910999	SAFETY GUIDE	1
222	908093	SPRING	1
301	911015	HOUSING W/ WARN	1
302	910775	GASKET (END CAP)	1

Parts List for FR350A Type 1

Item Number	Part Number	Description	Qty Required
303	910776	END CAP (NPT3/8-1	1
304	894752	BOLT	10
305	887077	1/4 MALE QUICK CP	1
306	887078	1/4 PROT CVR(AIR	1
401	A08116	NOSE PIECE	1
401	A08116	NOSE PIECE	1
401	A08116	NOSE PIECE	1
402	894800	BOLT	10
403	886070	ROLLED PIN	1
404	911016	MAGAZINE ASSY	1
405	911001	PUSHER	1
406	897431	SPRING	1
407	911002	LOCKOUT- PUSHER (M4X	1
408	A09213	COVER	1
408	897429	COVER	1
409	883866	BOLT	10
410	897428	SPRING	1
411	883882	LOCK NUT	1
412	883999	BOLT	10
413	911010	STEEL CHANNEL	1
414	910995	STOP PLATE	1
415	911008	COVER-PROTECTIVE MAG	1
416	884001	BOLT	10
417	886260	BOLT	10
418	910997	BRACKET	1
419	886105	LOCKNUT	1
420	886257	BOLT	10

Parts List for FR350A Type 1

Item Number	Part Number	Description	Qty Required
421	910782	FLAT WASHER (D13 X D	1
422	A09211	O-RING (11.58X2.13)	1
423	911011	SCREW ASSY -HEX SKT	1
424	910998	SPRING-SAFETY	1
425	A08115	SAFETY B ASSY	1
426	907907	RING	1
427	910787	THUMB WHEEL	1
428	910788	SAFETY A	1
429	907905	E-RING	1
430	897384	NOSE CUSHION	1
434	897427	PIN	1
435	886440	ROLLING ELEMENT	1
438	890722	TRIGGER PIVOT PIN	1
800	884293	AIR TOOL OIL (18CC)	1
856	910450	AS/A OVERHAUL KIT	1
856	60093	OVERHAUL KIT	1
856	884299	HEX WRENCH (5MM)	1
856	893579	SAFETY GLASSES	1
861	910441	CARRYING CASE	1