



Parts List for FS140LI Type 1

Item Number	Part Number	Description	Qty Required
1	90515028	CLAMSHELL SET	1
2	90502371	SCREW	1
3	90512557	REAR COVER	1
4	90503108	LABEL	1
5	90502056	SWITCH COVER	1
6	90502366	PCB ASSEMBLY	1
7	90513642	SPEED SELECTOR	1
8	90504540	KEYLESS CHUCK	1
9	149518-01	SCREW	1
10	90503924	TRANSMISSION ASSY.	1
11	90509372	MOTOR & SWITCH	1
12	90512559	F/R ACTUATOR	1
13	90505556	PCB ASSEMBLY	1
14	90503664	SCREW	4
15	90503075	BATTERY PACK	1
16	90508085	FOOT FRONT	1
17	90505555	SOCKET	1
18	90502350	REAR FOOT	1
19	90512726	SIDE COVER	1
20	90512560	SIDE COVER	1
21	90512562	WARNING LABEL	1
22	90505174	SCREW	5
23	90503663	SCREW	2
24	90502345	NUT	1
25	90505176	SCREW	1
26	90503670	INSULATOR	1
27	90512563	NAMEPLATE	1

Parts List for FS140LI Type 1

Item Number	Part Number	Description	Qty Required
871	90502367-01	CHARGER	1