

Parts List for FS2407CSL Type 1

Item Number	Part Number	Description	Qty Required
1	5147689-00	LASER ASSEMBLY	1
2	90515630	CLAMSHELL SET	1
4	5147698-00	UPPER GUARD	1
5	5147699-00	LOWER GUARD	1
6	90502026	MOTOR & GEARBOX	1
8	90515361	SPINDLE LOCK	1
9	5147708-00	SHOE ASSY.	1
10	5147707-00	BUMPER GUARD	1
11	5147826-00	CLAMP WASHER	1
12	5148017-00	COVER PLATE	1
13	5148016-00	SPINDLE FILTER	1
14	5148018-00	HOLDER	1
18	5147827-00	BLADE BOLT	1
19	5149023-00	TORSION SPRING	1
20	497479-00	RING,RETAINING	1
21	5148161-00	BAFFLE	1
23	90508884	SWITCH ASSEMBLY	1
24	5147897-00	LOCK-OFF BUTTON	1
27	624736-00	ALLEN WRENCH	1
28	5149025-00	RUBBER PLUG	1
30	90508411	NUT	1
31	497575-01	E-CLIP	1
32	5148556-00	WASHER TRANS. PVC	1
34	5148783-00	WASHER	1
35	5148761-00	FLAT WASHER	1
36	5148557-00	SCREW	1
38	90502470	LEVER, ADJUST.	1

Parts List for FS2407CSL Type 1

Item Number	Part Number	Description	Qty Required
39	90502474	RUBBER COVER	1
40	90503101	NUT	1
41	5148755-00	SCREW	4
43	5148739-00	SCREW	4
46	5148777-00	SELF TAPPING SCREW	1
47	486562-00	SCREW	1
48	90501917	SCREW	5
49	90501918	SCREW	4
51	5148944-00	SPRING,LOCK-OFF	1
52	497557-01	HEX NUT	1
55	497558-01	BOLT	1
56	90508048	BOLT,CARRIAGE	1
57	5147692-00	COVER	1
59	90507041	NAMEPLATE	1
61	90501260	LABEL	1
62	90501259	WARNING LABEL	1
856	5148141-00	BLADE,CDLS.SAW	1
866	90504665	BATTERY PACK	1
867	5102026-00	BATTERY CAP	1
871	90553447	CHARGER	1